



EAC Series

EAC-303/EAC-306

# EAC Series Programmable 1 Phase / 3 Phase AC Power Source

User Manual

E 1.03



## WARRANTY

EEC certifies that the instrument listed in this manual meets or exceeds published manufacturing specifications. This instrument was calibrated using standards that are traceable to the National Institute of Standards Taiwan.

Your new instrument is warranted to be free from defects in workmanship and material for a period of (3) year from date of shipment. During the warranty period, you must return the instrument to EEC or its branches or its authorized distributor for repair. EEC reserves the right to use its discretion on replacing the faulty parts or replacing the assembly or the whole unit.

Follow below states, EEC will void your warranty.

Operate under non-normal , contrived omission, or accidental calamity (including, temblor, floods, rebellion, and fire etc.)

Any non-authorized modifications, tampering or physical damage.

Elimination of any connections in the earth grounding system or bypassing any safety systems.

Use of non-authorized parts in the repair of this instrument. Parts used must be parts that are recommended by EEC as an acceptable specified part.

This warranty does not cover accessories not of EEC manufacture.

Except as provided herein, EEC makes no warranties to the purchaser of this instrument and all other warranties, express or implied (including, without limitation, merchantability or fitness for a particular purpose) are hereby excluded, disclaimed and waived.

EEC recommends that your instrument be calibrated on a twelve month cycle.

# Compliance Information

Conforms with the following product standards:

## EMC Standard

EN 61326-1:2013 Class A  
EN 61000-3-3:2008 / IEC 61000-3-3:2008  
EN 61000-3-11:2000 / IEC 61000-3-11:2005  
EN 61000-3-12:2011 / IEC 61000-3-12:2005  
EN 61326-1:2013 (Industrial Locations)  
EN 61000-4-2:2009 / IEC 61000-4-2:2008  
EN 61000-4-3:2006+A1:2008+A2:2010 / IEC 61000-4-3:2006+A1:2007+A2:2010  
EN 61000-4-4:2004+A1:2010 / IEC 61000-4-4:2004+A1:2010  
EN 61000-4-5:2006 / IEC 61000-4-5:2005  
EN 61000-4-6:2014 / IEC 61000-4-6:2013  
EN 61000-4-8:2010 / IEC 61000-4-8:2009  
EN 61000-4-11:2004 / IEC 61000-4-11:2004  
EN 61000-4-34:2007+A1:2009 / IEC 61000-4-34:2005+A1:2009

1. The product is intended for use in non-residential/non-domestic environments. Use of the product in residential/domestic environments may cause electromagnetic interference.
2. Connection of the instrument to a test object may produce radiations beyond the specified limit.
3. Use high-performance shielded interface cable to ensure conformity with the EMC standards listed above.

## Safety Standard

IEC 61010-1:2010 / EN 61010-1:2010

## CONTENT

<b>CHAPTER 1. Introduction .....</b>	<b>1</b>
1.1 Glossary of Terms .....	1
1.2 Safety Precautions .....	3
1.3 Service and Maintenance .....	3
<b>CHAPTER 2. Getting Started .....</b>	<b>5</b>
2.1 Unpacking and Inspection .....	5
2.2 Input / Output Power Considerations .....	5
2.3 Environmental Conditions .....	10
2.4 Packaging .....	10
<b>CHAPTER 3. Specifications and Controls .....</b>	<b>12</b>
3.1 Specifications .....	12
3.2 Instrument Controls .....	19
<b>CHAPTER 4. Programming Instructions .....</b>	<b>23</b>
4.1 Powering on the Instrument .....	23
4.2 System Parameters Description .....	26
4.3 Editing System Parameters .....	29
4.4 Using Memories and Steps (PROGRAM Mode only) .....	39
4.5 Test Parameters Description .....	43
4.6 Editing Test Parameters .....	48
4.7 Reviewing Test Results .....	67
<b>CHAPTER 5. Test Modes .....</b>	<b>69</b>
5.1 Description of Test Modes .....	69
5.2 Initializing a Test in PROGRAM Mode .....	69
5.3 Initializing a Test in MANUAL Mode .....	71
<b>CHAPTER 6. Displayed Messages .....</b>	<b>74</b>
6.1 OTP – Over Temperature Protection .....	74
6.2 OCP – Over Current Protection .....	74
6.3 OPP – Over Power Protection .....	74
6.4 OVP – Output Voltage Protection .....	74
6.5 A-SH – Amplifier Shutdown Protection .....	75
6.6 RCP – Reverse Current Protection .....	75
6.7 LVP – Low Voltage Protection .....	75
<b>CHAPTER 7. Remote PLC .....</b>	<b>76</b>
7.1 Signal Output .....	76
7.2 Signal Input - 7 Memory Recall .....	76
<b>CHAPTER 8. Bus Remote Interface GPIB/RS-232 .....</b>	<b>78</b>
8.1 RS-232 Interface .....	78

8.2 GPIB Interface.....	79
8.3 Interface Functions.....	80
8.4 GPIB/RS-232 Interface Command List.....	81
8.4.5 System Commands and Companion Queries.....	92
8.4.6 IEEE 488.2 Common Commands.....	95
<b>CHAPTER 9. Calibration Procedure .....</b>	<b>98</b>
9.1 Enter Calibration Mode .....	98
9.2 Reference for Calibration .....	106
<b>CHAPTER 10. Options .....</b>	<b>108</b>
10.1 GPIB Interface.....	108
10.2 Smart Config.....	108
10.3 Ethernet Card .....	108

# CHAPTER 1. Introduction

## 1.1 Glossary of Terms

**Alternating Current (AC)** - current that reverses direction on a regular basis (usually 60 times per second in the United States). Measured in amps.

**AC Power Source** - An instrument that takes one AC voltage and frequency level and converts it into another AC voltage and frequency level.

**Amplifier** - a circuit that boosts an input signal from one level to another.

**Apparent Power** - The total power generated or consumed by a device due to real and reactive circuit components. Measured in VA (volt-amps).

**Calibration** - the process of comparing an unknown value with a reference standard and reporting the results. For example: *Applied = 1.30V, Indicated = 1.26V (or Error = -0.04V)*. Calibration *may* include adjustment to correct any deviation from the value of the standard.

**Crest Factor** - The ratio of peak current ( $I_{peak}$ ) to RMS current ( $I_{rms}$ ).

**Complex Power** – the vector sum of the real and reactive power components of a circuit. Measured in VA (volt-amps).

**Direct Current (DC)** - current that only flows in one direction. Direct current comes from a polarized source, meaning one terminal is always at a higher potential than the other. Measured in amps.

**Frequency** - The number of times a waveform completes a cycle in a period of time. Measured in hertz.

**Inrush Current** - A term used to describe the current needed to power a load upon start-up. Some loads require a large/inrush starting current in order to operate.

**Linear Power Source** - a power source that uses a simple amplifier to linearly increase the amplitude of the output waveform.

**OC Fold** - Over current fold back is a technology used in power sources that keeps output current constant by reducing the voltage in order to power loads that may have a high inrush

current.

**PFC** - Power Factor Correction is a method by which an inductance is inserted into the input circuit of a power source to improve the power factor and overall efficiency of the system.

**Phase Angle** - the degree of measurement that corresponds to an AC waveform's amplitude. Measured from 0 – 360 degrees.

**PLC** - Programmable Logic Control is an automation method using relay or digital technology.

**Power** - A generic term used to describe electrical work being done. There are many types of power, including real power, reactive power, apparent power, and complex power.

**Power factor** - The ratio of real power (watts) to apparent power (VA). Based on a scale from 0 to 1 to determine how reactive and resistive a load is.

**Reactive Power** – the power absorbed by capacitive or inductive elements in a circuit. This power does no work. Measured in VAR (volt-amps reactive).

**Real Power** – the power that performs work in a circuit. Measured in watts.

**Response Time** - The time that is needed to regulate the voltage, current, frequency, and power output when a load is added to the power source.

**Safety Agency Listing** - A safety mark given to a product that has met stringent benchmarks as classified by the authorized agency.

**Steady State Current** - A term used to describe the current when the load is running nominally after the inrush current.

**Switching Power Source** - A power source that uses switching technology (integrated circuits and components) in order to generate the output waveform.

**Total Harmonic Distortion (THD)** - A percentage that is used to identify the degree of the noise/unclean signal in a power source's output waveform.

**Transient** - a momentary change (spike or dip) in a voltage or current waveform that can affect the performance of the DUT.

**Verification** - comparison of measured results against a specification, usually the

manufacturer's published performance figures for the product (e.g. *Error* =  $-0.04V$ , *Spec* =  $\pm 0.03V$ , result: "FAIL").

**Voltage** - The amount of force that is needed to move current from point to point. Measured in volts.

## 1.2 Safety Precautions

This product and its related documentation must be reviewed for familiarization with safety markings and instructions before operation. Before applying power verify that the instrument is set to the correct line voltage and the correct fuse is installed.

To prevent accidental injury or death, these safety procedures must be strictly observed when handling and using the test instrument.

Product will be marked with this symbol when it is necessary to refer to the operation and service manual in order to prevent injury or equipment damage.



Product will be marked with this symbol at connections that require earth grounding.

## 1.3 Service and Maintenance

### User Service

To prevent electric shock do not remove the instrument cover. There are no user serviceable parts inside. Routine maintenance or cleaning of internal parts is not necessary. Any external cleaning should be done with a clean dry or slightly damp cloth. Avoid the use of cleaning agents or chemicals to prevent any foreign liquid from entering the cabinet through ventilation holes or damaging controls and switches, also some chemicals may damage plastic parts or lettering. Any replacement cables and high voltage components should be acquired directly from EEC or its distributors.

### Service Interval

The instrument must be returned at least once a year to an EEC authorized service center for calibration and inspection of safety related components. EEC will not be held liable for

injuries suffered if the instrument is not properly maintained and safety checked annually.

### **User Modifications**

Unauthorized user modifications will void your warranty. EEC will not be responsible for any injuries sustained due to unauthorized equipment modifications or use of parts not specified by EEC. Instruments returned to EEC with unsafe modifications will be returned to their original operating condition at the customer's expense.

## CHAPTER 2. Getting Started

This section contains information for the unpacking, inspection, preparation for use and storage of your EEC product.

### 2.1 Unpacking and Inspection

Your instrument was shipped in a protective shipping carton designed to protect the instrument through the shipping process. If the shipping carton is damaged, inspect the contents for visible damage such as dents, scratches, or broken display. If the instrument is damaged, notify the carrier and EEC's customer support department. Please save the shipping carton and packing material for the carrier's inspection. Our customer support department will assist you in the repair or replacement of your instrument. Please do not return your product without first notifying us. Please retain all of the original packaging material.

### 2.2 Input / Output Power Considerations

Special care should be taken when making connections to the input and output terminal blocks located on the rear panel of the EAC series. Ensure that the appropriate wire gauges are used to assemble a satisfactory line cord. Failure to assemble a quality line cord could result in fire or personal injury. Refer to the following table for input/output current requirements:

#### FIGURES



*The power switch that is included in the instrument is not considered a disconnecting device. It only disconnects one current carrying conductor to power off the device. The user should configure the equipment with an external switch or circuit breaker for disconnecting it from each operating energy supply source. In compliance with EN61010-1 for permanently connected equipment this switch should meet the following guidelines.*

- a) It shall be included in the building installation.*
- b) It shall be in close proximity to the equipment and within easy reach of the OPERATOR.*
- c) It shall be marked as the disconnecting device for the equipment.*
- d) It shall not interrupt the protective earth conductor.*

#### 2.2.1 Selecting the Appropriate Wire Gauge

Below is a table which provides recommended appropriate wire gauges for the EAC series.

### EAC-303

	Output					SENSE				Input		
Phase	R	S	T	N	G	R	S	T	N	G	N	L
1Ø2W	10	-	-	10	12	10	-	-	10	12	14	14
1Ø3W	18	18	-	18	20	18	18	-	18	-	-	-
3Ø4W	18	18	18	18	20	18	18	18	18	-	-	-
DC	18	-	-	18	-	18	-	-	18	-	-	-

### EAC-306

	Output					SENSE				Input					
Phase	R	S	T	N	G	R	S	T	N	R-L	S-L	T-L	R-N	S-N	T-N
1Ø2W	8	-	-	8	10	8	-	-	8	10			10		
1Ø3W	16	16	-	16	18	16	16	-	16	-	-	-	-	-	-
3Ø4W	16	16	16	16	18	16	16	16	16	16	16	16	short	short	short
DC	10	-	-	10	-	10	-	-	10	-	-	-	-	-	-


### 2.2.2 Power Cable

#### WARNING

Before connecting power to this instrument, the protective ground (Earth) terminals of this instrument must be connected to the protective conductor of the line (mains) power cord. **The main terminal of EAC series** shall only be connected to a connector provided with a protective ground (earth) contact. This protective ground (earth) **must not be defeated** by the use of an extension cord without a protective conductor (grounding).

### EAC Input Power Considerations

The EAC can be powered with several different input power configurations. Refer to the diagram below for connecting a single phase, 3 phase wye, and 3 phase delta power source to the instrument:



## EAC Output Power Considerations



Figure 1: Input/Output Terminal Block and Output Connection Description




Figure 2: 3 $\emptyset$ 4W Configuration (Wye Load)




Figure 3: 3 $\emptyset$ 3W Configuration (Delta Load)




Figure 4: 1Ø2W Configuration



Figure 5: 1Ø3W Configuration




Figure 6: DC Output Configuration

## 2.3 Environmental Conditions

### Operating Environment (For indoor use only)

Temperatures: 0° - 40° C (32° - 104° F)

Relative humidity: 20% - 80%

Altitude: 2,000 meters (6,562 feet)

The instrument should also be protected against temperature extremes which may cause condensation within the instrument.

### Storage and Shipping Environment

This instrument may be stored or shipped in environments with the following limits:

Temperature... ..-40° to +55° C

Altitude... ..7,620 meters (25,000 feet)

## 2.4 Packaging

### Original Packaging

Please retain all original packaging materials that you originally received. If you are returning your instrument to us for servicing please repackage the instrument in its original container. Please enclose the instrument with all options, accessories and test leads. Also, please mark the container "FRAGILE" to insure proper handling. All returns must be accompanied by a return material authorization (RMA) number which is provided by the customer support

department. Failure to ship your instrument without a RMA number will result in additional fees for handling and storage.

### **Other Packaging**

If you have discarded the container please follow these guidelines:

- A wooden skid must be used.
- The instrument needs to be securely strapped to the skid.
- A protective double wall container must be placed over the instrument and also secured to the side.
- Mark the container “FRAGILE” to ensure proper handling.

For all other models, if you do not have the original packaging materials, please follow these guidelines:

- Wrap the instrument in a bubble pack or similar foam. Enclose the same information as above.
- Use a strong double-wall container that is made for shipping instrumentation. A 350 lbs. test material is adequate.
- Use a layer of shock-absorbing material 70 – 100 mm (3 to 4 inch) thick around all sides of the instrument. Protect the control panel with cardboard.
- Seal the container securely.
- Mark the container “FRAGILE” to insure proper handling.

EEC will not be responsible for any repair costs associated with shipping damage as a result of improper packaging. The customer is responsible for providing adequate shipping insurance coverage while shipping an instrument in the event of loss or damage while in transit.

## CHAPTER 3. Specifications and Controls

### 3.1 Specifications

Model			EAC-303	EAC-306
INPUT				
Phase			1Ø	1Ø or 3Ø
Voltage			200 - 240Vac ± 10%	1Ø : 200 - 240Vac ± 10% 3Ø3W : 200 - 240Vac ± 10% 3Ø4W : 346 - 416Vac ± 10%
Frequency			47 - 63 Hz	
Max. Current			23A	1Ø : 45A 3Ø3W : 26A 3Ø4W : 15A
Power Factor			0.97	
AC OUTPUT				
Max. Power	1Ø2W		3000VA	6000VA
	1Ø3W		2000VA	4000VA
	3Ø4W		3000VA	6000VA
Max. Current (r.m.s)*1	1Ø2W	0 - 150V	27.6A	55.2A
		0 - 300V	13.8A	27.6A
	1Ø3W	0 - 150V	9.2A	18.4A
		0 - 300V	4.6A	9.2A
	3Ø4W	0 - 150V	9.2A	18.4A
		0 - 300V	4.6A	9.2A
Inrush Current (peak)	1Ø2W	0 - 150V	110.4A	220.8A
		0 - 300V	55.2A	110.4A
	1Ø3W	0 - 150V	36.8A	73.6A
		0 - 300V	18.4A	36.8A
	3Ø4W	0 - 150V	36.8A	73.6A
		0 - 300V	18.4A	36.8A
Phase			1Ø2W, 1Ø3W, 3Ø4W	
Total Harmonic Distortion (THD)			<0.5% (Resistive Load) at 40.0 - 70.0Hz and output voltage within the 80 - 140Vac at Low Range or the 160 - 280Vac at High Range. <1% (Resistive Load) at 70.1 - 1000Hz and output voltage within the 80 - 140Vac at Low Range or the 160 - 280Vac at High Range.	
Inrush Current			≥4	
Crest Factor			≥3	
Line Regulation			± 0.1V	

Load Regulation (Hardware)				± (1% of output +1V) at Resistive Load , < 400µS response time			
Load Regulation (Software)				± 0.2V, < 1s response time			
DC offset				≤ ±5mV			
SETTING							
Voltage	Range	1Ø2W		0.0 - 300VAC, 150 / 300V Auto Range			
		1Ø3W		0.0 - 300 VAC (phase), 0.0 - 600 VAC (line), 150 / 300V Auto Range			
		3Ø4W		0.0 - 300 VAC (phase), 0.0 - 520 VAC (line), 150 / 300V Auto Range			
	Resolution		0.1V				
	Accuracy		± (0.2% of setting + 3 counts)				
Frequency	Range		40 - 1000Hz Full Range Adjust				
	Resolution		0.1Hz at 40.0 - 99.9Hz , 1Hz at 100 - 1000Hz				
	Accuracy		± 0.03% of setting				
Starting&Ending	Range		0 - 359º				
Phase Angle	Resolution		1º				
	Accuracy		± 1º(45 - 65HZ)				
Current Hi Limit (OC Fold=OFF) OC Fold Back (OC Fold = ON)	Range	1Ø2W	L	0.10 - 27.60A		0.10 - 55.20A	
			H	0.10 - 13.80A		0.10 - 27.60A	
		1Ø3W	L	0.01 - 9.20A		0.01 - 18.40A	
			H	0.01 - 4.60A		0.01 - 9.20A	
		3Ø4W	L	0.01 - 9.20A		0.01 - 18.40A	
			H	0.01 - 4.60A		0.01 - 9.20A	
	Resolution		0.01A				
	Accuracy		± (2.0% of setting + 2 counts)				
	OC Fold Back Response Time				< 1.4s		
DC OUTPUT							
Max. Power				3000W		6000W	
Max.	0 - 210V			14.4A		28.8A	
Current	0 - 420V			7.2A		14.4A	
Ripple & Noise (rms)	Range		L	< 700mV			
			H	< 1100mV			
Ripple and Noise (p-p)				< 4.0Vp-p			
SETTING							
Voltage	Range		0 - 210V / 0 - 420V Selectable				
	Resolution		0.1V				
	Accuracy		± (0.2% of setting + 3 counts)				
Current Hi	5V - 210V		0.10 - 14.40A		0.10 - 28.80A		
Limit (OC	5V - 420V		0.10 - 7.20A		0.10 - 14.40A		
Fold=OFF)	Resolution		0.01A				

OC Fold Back (OC Fold = ON)	Accuracy		± (2.0% of setting + 2 counts)		
MEASUREMENT					
Voltage (AC)	Range		0.0 - 420.0V		
	Resolution		0.1V		
	Accuracy		± (0.2% of reading + 3 counts) at Voltage > 5V		
Voltage (DC)	Range		0.0 - 420.0V		
	Resolution		0.1V		
	Accuracy		± (0.2% of reading + 5 counts) at Voltage > 5V		
Frequency	Range		0.0 - 1000Hz		
	Resolution		0.1Hz		
	Accuracy		± 0.1Hz (501 - 1000Hz, Accuracy ±0.2Hz)		
Current (AC)	Range	1Ø2W		0.05A - 39.00A	0.05A - 78.00A
		1Ø3W	L	0.005A - 1.200A	0.005A - 2.400A
			H	1.00A - 13.00A	2.00A - 26.00A
		3Ø4W	L	0.005A - 1.200A	0.005A - 2.400A
			H	1.00A - 13.00A	2.00A - 26.00A
		Resolution <sup>*2</sup>		L	0.001A
			H	0.01A	
	Accuracy	1Ø2W		± (1% of reading + 5 counts) at 40.0 - 500Hz ± (1% of reading + 5 counts) at 501 - 1000Hz and CF < 1.5 ※Current (peak) ≤ 82.8A at Voltage > 5V	± (1% of reading + 5 counts) at 40.0 - 500Hz ± (1% of reading + 5 counts) at 501 - 1000Hz and CF < 1.5 ※Current (peak) ≤ 165.6A at Voltage > 5V
		1Ø3W	L	± (1% of reading + 5 counts) at 40.0 - 500Hz ± (1% of reading + 5 counts) at 501 - 1000Hz and CF < 1.5 ※Current (peak) ≤ 3.6A at Voltage > 5V	± (1% of reading + 5 counts) at 40.0 - 500Hz ± (1% of reading + 5 counts) at 501 - 1000Hz and CF < 1.5 ※Current (peak) ≤ 7.2A at Voltage > 5V
				H	± (1% of reading + 5 counts) at 40.0 - 500Hz ± (1% of reading + 5 counts) at 501 - 1000Hz and CF < 1.5 ※Current (peak) ≤ 27.6A at Voltage > 5V

				$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz $\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 501 - 1000Hz and CF < 1.5 $\times \text{Current (peak)} \leq 3.6\text{A}$ at Voltage > 5V	$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz $\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 501 - 1000Hz and CF < 1.5 $\times \text{Current (peak)} \leq 7.2\text{A}$ at Voltage > 5V
		3Ø4W	L	$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz $\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 501 - 1000Hz and CF < 1.5 $\times \text{Current (peak)} \leq 27.6\text{A}$ at Voltage > 5V	$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz $\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 501 - 1000Hz and CF < 1.5 $\times \text{Current (peak)} \leq 55.2\text{A}$ at Voltage > 5V
Current (DC)	Range			0.05A - 19.50A	0.05A - 39.00A
	Resolution			0.01A	
	Accuracy			$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at Voltage > 5V	
Current Peak	Range	1Ø2W		0.0A - 114.0A	0.0A - 228.0A
		1Ø3W		0.0A - 38.0A	0.0A - 76.0A
		3Ø4W		0.0A - 38.0A	0.0A - 76.0A
	Resolution			0.1A	
	Accuracy			$\pm (1\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 70.0Hz $\pm (1.5\% \text{ of reading} + 10 \text{ counts})$ at 70.1 - 500Hz $\pm (1.5\% \text{ of reading} + 10 \text{ counts})$ at 501 - 1000Hz and CF < 1.5 at Voltage > 5V	
Power (AC)	Range	1Ø2W		0W - 3900W	0W - 7800W
		1Ø3W	L	0.0W - 120.0W	0.0W - 240.0W
			H	100W - 1300W	200W - 2600W
		3Ø4W	L	0.0W - 120.0W	0.0W - 240.0W
			H	100W - 1300W	200W - 2600W
		Resolution		L	0.1W
				H	1W
	Accuracy	1Ø2W		$\pm (2\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz and PF $\geq 0.2$ $\pm (2\% \text{ of reading} + 15 \text{ counts})$ at 501 - 1000Hz and PF $\geq 0.5$ at Voltage > 5V	
		1Ø3W	L	$\pm (2\% \text{ of reading} + 15 \text{ counts})$ at 40.0 - 500Hz and PF $\geq 0.2$ $\pm (2\% \text{ of reading} + 30 \text{ counts})$ at 501 - 1000Hz and PF $\geq 0.5$ at Voltage > 5V	
			H	$\pm (2\% \text{ of reading} + 5 \text{ counts})$ at 40.0 - 500Hz and PF $\geq 0.2$ $\pm (2\% \text{ of reading} + 15 \text{ counts})$ at 501 - 1000Hz and PF $\geq 0.5$	

				at Voltage > 5V	
		3Ø4W	L	± (2% of reading + 15 counts) at 40.0 - 500Hz and PF ≥ 0.2 ± (2% of reading + 30 counts) at 501 - 1000Hz and PF ≥ 0.5 at Voltage > 5V	
			H	± (2% of reading + 5 counts) at 40.0 - 500Hz and PF ≥ 0.2 ± (2% of reading + 15 counts) at 501 - 1000Hz and PF ≥ 0.5 at Voltage > 5V	
Power (DC)	Range		0W - 3900W		0W - 7800W
	Resolution		1W		
	Accuracy		± (2% of reading + 5 counts) at Voltage > 5V		
Power Apparent (VA)	Range	1Ø2W		0VA - 3900VA	0VA - 7800VA
		1Ø3W	L	0.0VA - 120.0VA	0.0VA - 240.0VA
			H	100VA - 1300VA	200VA - 2600VA
		3Ø4W	L	0.0VA - 120.0VA	0.0VA - 240.0VA
			H	100VA - 1300VA	200VA - 2600VA
	Resolution		L	0.1VA	
			H	1VA	
	Accuracy		V×A, Calculated value		
Power Reactive (Q)	Range	1Ø2W		0VAR - 3900VAR	0VAR - 7800VAR
		1Ø3W	L	0.0VAR - 120.0VAR	0.0VAR - 240.0VAR
			H	0VAR - 1300VAR	0VAR - 2600VAR
		3Ø4W	L	0.0VAR - 120.0VAR	0.0VAR - 240.0VAR
			H	0VAR - 1300VAR	0VAR - 2600VAR
	Resolution		L	0.1VAR	
			H	1VAR	
	Accuracy		$\sqrt{(VA)^2 - (W)^2}$ , Calculated value		
Power Factor	Range		0 - 1.000		
	Resolution		0.001		
	Accuracy		W / VA ,Calculated and displayed to three significant digits		
Crest Factor	Range		0 - 10.00		
	Resolution		0.01		
	Accuracy		Ap / A ,Calculated and displayed to two significant digits		
GENERAL					

Transient (only for 40 - 70Hz)	Trans-Volt 0.0 - 300.0V, Resolution 0.1V Trans-Site 0° - 359°, Resolution 1° Trans-Time 0.5 - 999.9mS, Resolution 0.1mS Trans-Cycle 0 - 9999, 0 = Constant		
Operation Key Feature	Soft key, Numeric key, Rotary Knob.		
Remote Input Signal	Test, Reset, Interlock, Recall program memory 1 through 7		
Remote Output Signal	Pass, Fail, Test-in Process		
Key Lock	Yes, Password Driven		
Memory	50 memories, 9 steps / memory		
Synch Output Signal	ON / OFF / EVENT / Ext Trigger in the Program mode, Output Signal 5V, BNC type, Between the sync signal and the output voltage will be 0.5ms time difference		
Alarm Volume Setting	Range: 0 - 9 ; 0 = OFF, 1 is softest volume, 9 is loudest volume		
Graphic Display	240 x 64 dot resolution Monographic LCD / Contrast 9 Levels 1 - 9		
Interface	Standard USB & RS232, Option GPIB, Ethernet		
Protection Circuits	OCP, OVP, OPP, OTP, RCP (Over Current, Over Voltage, Over Power, Over Temp, Reserve Current)		
PFC	PF ≥ 0.97 at Full load		
Efficiency	≥78% (at Full load)		
Auto loop cycle	0 = Continuous, OFF, 2 - 9999		
V sense	Yes		
Over Current Fold Back	On / Off, Setting On when output current over setting Hi-A value it will fold back output voltage to keep constant output current is setting Hi-A value, Response time <1400ms		
CE Mark	Yes		
Operation Environment	0 - 40°C / 20 - 80% RH		
Dimension, mm <sup>*3</sup>	W	430	
	H	400 (487)	
	D	500 (560)	
Weight	48kg		57kg

\*1 At working voltage 110V / 220V

Product specifications are subject to change without notice.

\*2 a. When output frequency ≥100Hz & ≤500Hz & N-G short, the current meter guarantee minimum current from 0.010A

b. When output frequency ≥500Hz & N-G short, the current meter guarantee minimum current from 0.020A

c. When output frequency ≥100Hz & ≤500Hz & N-G short, the current meter guarantee minimum current from 0.020A at 600V models.

d. When output frequency ≥500Hz & N-G short, the current meter guarantee minimum current from 0.030A at 600V models

\*3 Figure in parentheses are maximum values

**【 Ordering Information 】**

EAC-303 Programmable AC Power Source 0 - 300V / 40 - 1000Hz (3KVA)


EAC-306 Programmable AC Power Source 0 - 300V / 40 - 1000Hz (6KVA)

Opt.627 GPIB Interface Card

Opt.647 Ethernet Card

## 3.2 Instrument Controls


### 3.2.1 Front Panel Controls




- 1. Power Switch:** Rocker style power switch with international ON ( | ) and OFF (0).
- 2. Graphic LCD:** 240 x 64 Monographic LCD.
- 3. Soft Keys:** Multifunctional selection keys used to select parameters, select screens, and edit parameters.
- 4. Number Keypad:** Keys used to enter numerical data.
- 5. Delete Key:** Used to delete text characters and numerical data.
- 6. Rotary Knob:** Used to adjust the voltage output in MANUAL Mode, or DC+/DC- Mode.
- 7. Lock Key:** Used to lock out the front panel.
- 8. Lock LED:** When lit indicates the instrument front panel is locked.
- 9. Test/Reset Key:** Used to turn ON/OFF output voltage, or used to reset the instrument in the event of a failure condition.
- 10. Test/Reset LED:** When lit indicates output is active, or when blinking indicates the instrument is in a failure condition.

3.2.2 Rear Panel Controls

EAC-303



## EAC-306



**1. THERMAL FAN:** To cool the instrument.

**2. Ext Trigger Connector:** Provides the capability to monitor a 5 VDC output signal.

**3. Remote Signal Output :** Provides output to monitor PASS, FAIL, Test-In-Process via relay contact closures.

**4.Remote signal Input:** 9-Pin D subminiature male connector for remote control of TEST, RESET, and REMOTE INTERLOCK DISABLE functions, as well as MEMORY SELECTION

**5.Interface Card:** Optional USB with RS-232 or GPIB

**6.External Sense Output Terminal Block:** provides screw terminals for external voltage sense leads

**7 .Output Terminal Power Block:** provides output power to the DUT.

Input Terminal Power Block: provides input power to the instrument.

Model EAC-303 requires: 1Ø 200-240 VAC, 47-63 Hz.

Model EAC-306 requires: 1Ø 200~240 Vac; 3Ø 3W : 200~240 Vac; 3Ø 4W : 346~416 Vac

### 3.2.3 Soft Keys

The soft keys enable the operator to navigate through the instrument, change the meter display, name files, and change parameters. Below is a list of all available soft keys.

Soft Key	Description
Memory	Allows you to enter the memory location to change a memory
Step	Allows you to change step location
Edit	Allows you to edit parameters
<more>	Allows you to move to additional selections
Result	Allows you to review the results after a test
System	Allows you to change the instruments settings and parameters
Exit	Allow you to exit the current screen
Name	Allow you to name a memory
List	Allows you to see the list of memories available
v	Allows you to scroll through the list sequentially, or move down a character listing
Page ^	Allows you to page up through the list
Pagev	Allows you to page down through the list
Load	Allows you to load a memory
Enter	Allows you to enter a parameter
Esc	Allows you to exit a parameter setting screen
<top>	Allows you to move to the previous screen of selections
>	Allows you to move to the right through a character listing
<	Allows you to move to the left through a character listing
Select	Allows you to select a memory
Meter	Allows you to toggle through the different meter settings/readings
Edit	Allows you to enter a parameter screen to change a parameter
^	Allows you to scroll through the list sequentially
Prev	Allows you to scroll to the previous parameter setting
Next	Allows you to scroll to the next parameter setting
Change	Allows you to open up the parameter for changing
Result	Allows you to open up the results screen
System	Allows you to open up the parameters for the system
Cycle	Allows you to open the cycle mode
Keypad	Allows you to open the numeric keypad in test mode
Trig.	Allows you to trigger the surge/drop parameters in test mode

## CHAPTER 4. Programming Instructions

### 4.1 Powering on the Instrument

Turn on the Power switch located on the lower left-hand corner of the front panel.

After a few seconds the Initialization screen will change to the set screen. The Set screen will be displayed as follows when in PROGRAM Mode:

M 1 - 1	1.0 s	F : 50.0 Hz	CF : 0.00	Memory	
Set		A : 0.00 A	Ap : 0.0	Step	
3 Ø 4 W : R	Phase	P : 0 W	VA : 0	Edit	
		Q : 0 VAR	PF : 0.000	< more >	
115.0 V		0.00 A			

If you press the <more> soft key within the Set screen, the soft keys will change to include Result, System, and <top> in the PROGRAM Mode.

M 1 - 1	1.0 s	F : 50.0 Hz	CF : 0.00	Result	
Set		A : 0.00 A	Ap : 0.0	System	
3 Ø 4 W : R	Phase	P : 0 W	VA : 0		
		Q : 0 VAR	PF : 0.000	< top >	
115.0 V		0.00 A			

If you are in MANUAL Mode there will not be a step number 1 next to the M 1 and the Set screen will appear as follows:

M 1		F : 50.0 Hz	CF : 0.00	Memory	
Set		A : 0.00 A	AP : 0.0	Step	
		P : 0 W	VA : 0	Edit	
		Q : 0 VAR	PF : 0.000	< more >	
120.0 V		0.00 A			

If you press the <more> soft key within the Set screen, the soft keys will change to Result, System, and <top> in the MANUAL Mode.

M 1		F : 50.0 Hz	CF : 0.00	Result	
Set		A : 0.00 A	AP : 0.0	System	
		P : 0 W	VA : 0		
		Q : 0 VAR	PF : 0.000	< top >	
120.0 V		0.00 A			

#### 4.1.1 Set Screen Description

When the instrument is in the Set screen the parameters indicate their current settings.

However, when the indicator LED is active on the Test/Reset key the parameter settings will display their output value.

Set Screen Parameters	Description of Parameters
M1-1	Memory and step location
1.0s	Instrument timer for output
F: 50.0 Hz	Frequency
Ap:	Peak Current
Set	Status of instrument at the present time. Possible readings are set, dwell, pass, abort, or other failure conditions.
P: 0.0W	Power
A: 0.000A	Current
PF: 0.000	Power Factor
Memory	Memory soft key used to change memory location
120.0V (left meter reading)	Meter for voltage
0.00A (right meter reading)	Meter for parameters of F, Ap, P, A & PF
Q: 0 VAR	Reactive Power
VA: 0 A	Apparent Power
CF: 0.00	Crest Factor
Parall-Master	Indicates the instrument is set up in Parallel mode as the master (Option)
Parall-Slave	Indicates the instrument is set up in Parallel mode as the master (Option)
1Ø3W: L1-N	Indicates the instrument is set up in 1Ø3W mode as L1-N (Option)
1Ø3W: L2-N	Indicates the instrument is set up in 1Ø3W mode as L2-N (Option)
3Ø4W: R Phase	Indicates the instrument is set up in 3Ø4W mode as Phase A (Option)
3Ø4W: S Phase	Indicates the instrument is set up in 3Ø4W mode as Phase A (Option)
3Ø4W: T Phase	Indicates the instrument is set up in 3Ø4W mode as Phase A (Option)

#### 4.1.2 Security

##### Creating a Password

Creating a password prevents unauthorized access to the Lock parameters in the System menu. Once a password has been created, lock functions will require the password to access them.

Press and hold the <top> soft key while powering up the instrument, the Edit Password

screen should now be displayed. The display will appear as follows:

EDIT PASSWORD	
New Password =	<input type="password"/>
Confirm Password =	<input type="password"/>
Set the Password to 0 to disable.	
Esc	

You may now type in the new password using the numeric keypad. Press the Enter key to accept the new password or press the Esc key to escape. After you type in your new password, you will be required to confirm your new password by typing it again into the “Confirm Password” field. Press the Enter key to confirm the new password or press the Esc key to escape.

If the password is set to 0, the Lock and Mem Lock parameters may be accessed by editing Lock and Mem Lock soft keys in the System Parameters menu. In this case, the key lockout on the front panel is enabled by pressing the Lock button.

If the password has been set to anything but 0, a password entry pop-up screen will appear to access the Lock and Mem Lock parameters as well as key lockout on the front panel of the unit. The password default is preset to 0 at the factory.

### Forgotten Password

If you have forgotten your password, a new password should be entered or enter “0” to disable the password. The old password cannot be recovered.

### Secure Lock and Mem Lock Access

If a password has been created, when you press the Lock or Mem Lock soft key or the key lockout on the front panel, a password pop-up screen will appear. The pop-up message will appear as follows:

M 1-1 Set	20.0s F: 50.0Hz CF: 0.0	
100	<div> <div> Password <input type="password"/> </div> </div>	Esc

In order for you to access the Lock or Mem Lock parameters, you will now have to enter the proper password. If you have forgotten the password, please refer to the Forgotten Password instructions in the Security section.

#### 4.1.3 Lock

From the Set screen press the <more> soft key. Press the System soft key. Highlight the Lock parameter using the , soft keys. When the Lock parameter is highlighted, you may

turn the function ON and OFF by pressing the Change soft key. Press the Enter key to accept the new setting or the Esc key to cancel and return to the original setting. When the Enter key is pressed, the new security setting will take immediate effect.

Selecting Lock “ON” restricts access to parameter and system settings. The level of security is determined by the Mem Lock function.

#### 4.1.4 Mem Lock

From the Set screen press the <more> soft key. Press the System soft key. Highlight the Mem Lock parameter using the , soft keys. When the Mem Lock parameter is highlighted, you may turn the function ON and OFF by pressing the Change soft key. Press the Enter key to accept the new setting or the Esc key to cancel and return to the original setting.

Mem Lock is a sub-function of the Lock setting. In order for the Mem Lock function to work, the Lock must first be turned ON. Selecting the Mem Lock OFF will allow the user to access all available memory locations but restricts access to memory and step editing capabilities. Selecting the Mem Lock ON will allow the user to only run the currently loaded memory.

## 4.2 System Parameters Description

The system parameters change the overall operation of the AC power source. If the operator elects to edit the system parameters this will apply a universal change to every memory and step location for the AC power source when in the Test Parameters menu. The operator cannot independently change these settings from one memory or step location to another.

1. **Auto Run** - places the AC power source into one of two modes (PROGRAM/MANUAL). In the PROGRAM Mode the operator will have the ability to program individual memories and steps with user selectable testing parameters such as test time, high and low limits, etc.

In the MANUAL Mode the operator will have limited choices in selecting and editing testing parameters. The key difference is that in MANUAL Mode the operator cannot connect steps or have fixed testing times. The output is either ON or OFF in the MANUAL Mode.

2. **Out Mode** - configures the instrument for AC or DC voltage output.

3. **Single Step (PROGRAM mode)** - controls how the instrument will proceed from one test step to the next in a testing sequence when in the Auto Run mode of PROGRAM.

When this parameter is selected on the source will sequence from one test step to the next only when the Test/Reset key is pressed between each step. When the Single Step parameter is on the source will pause after each step has completed a test routine and passed based on the programmed testing parameters. If a PASS occurs for the step the operator can proceed to the next step in the sequence. If a FAIL occurs for the step the operator will not be able to proceed in the test sequence. They will have to restart from the beginning of the test sequence or step number one.

If the parameter is selected off the source will automatically sequence from one step the next regardless if a pass or failure has occurred for a particular step.

4. **Alarm** - controls the volume level of the alarm if a failure is detected. This setting is from 1 – 9 with 9 being the loudest volume level.

5. **Contrast** - controls the contrast of the display. The setting is from 1 – 9 with 9 being the darkest contrast.

6. **Power Up** - controls how the output will react once the power switch is toggled on. There are three selections (OFF, ON, LAST). When the parameter is in the OFF state the operator must initialize a test by pressing the Test/Reset key on power up. If the parameter is in the ON state the output will automatically be energized when the source is powered on. If the parameter is in the LAST state the source will provide an output according to how this setting was last programmed prior to powering off the source.

7. **Loop Cycle (PROGRAM Mode)** - allows the operator to program the source to automatically repeat an overall testing sequence when in the PROGRAM Mode. This eliminates the need for the operator to press the Test/Reset key or send multiple test commands to the source to repeat a test sequence. Loop Cycle is only selectable when the source is configured for AC output.

8. **V Hi-Lmt (MANUAL Mode)** - allows the operator to select a maximum voltage threshold or ceiling level when programming the output voltage in the testing parameters screen.

9. **V Lo-Lmt (MANUAL Mode)** - allows the operator to select a minimum voltage threshold or floor level when programming the output voltage in the testing parameters screen.

10. **F Hi-Lmt (MANUAL Mode)** - allows the operator to select a maximum frequency threshold or ceiling level when programming the output frequency in the testing parameters screen. F Hi-Lmt is only selectable when the source is configured for AC output.

11. **F Lo-Lmt (MANUAL Mode)** - allows the operator to select a minimum frequency threshold or floor level when programming the output frequency in the testing parameters screen. F Lo-Lmt is only selectable when the source is configured for AC output.

12. **Start Angle (MANUAL Mode)** - provides the operator the flexibility to select the starting angle of the sine wave when the output voltage is generated. Start Angle is only selectable when the source is configured for AC output.

13. **End Angle (MANUAL Mode)** - provides the operator the flexibility to select the ending angle of the sine wave when output voltage is terminated. End Angle is only selectable when the source is configured for AC output.

14. **Results** - changes how the data will be displayed on the LCD graphic display after a test is completed. There are three selections available (LAST, ALL, P/F). The LAST setting displays the last step within the program sequence. The ALL setting will display the results of every step within the test sequence in a list format. The P/F, or PASS / FAIL, will display banner text of PASS or FAIL depending on the results of the test.

15. **OC Fold** - reduces the voltage, or folds the voltage back, in a linear fashion while maintaining a constant current to help run inductive loads.

16. **Transient (MANUAL Mode)** - allows the operator to perform transient testing while in Manual Mode. Transient is only selectable when the source is configured for AC output.

17. **Lock** – allows the operator to lock out the buttons and rotary knob on the front panel. The level of security is determined by the Mem Lock function.

18. **Mem Lock** – allows the operator to restrict access to memory and step locations. Lock must be set to ON in order for Mem Lock to function.

19. **Volt Sense** - configures the for internal or external voltage sensing. If internal is selected, the instrument will measure the output voltage at the output relay. If external is selected, the user must connect sensing wires from the Ls and Ns terminals located on rear panel output terminal block to the DUT. Using external sense will provide a more accurate measurement when a large voltage drop occurs over the output wires.

21. **Sync Signal** - provides an output signal that may be used to trigger an oscilloscope. The output signal is provided on the rear panel via the BNC connector labeled Sync. There are 4

Sync signal options: 1) OFF: the Sync output is disabled, 2) ON: the Sync signal is active during testing, 3) EVENT: the Sync signal is active when the output voltage changes

### 4.3 Editing System Parameters

To edit System parameters press the <more> soft key from the set screen so the soft keys read Result, System, and <top>. The screen should be as follows when in PROGRAM Mode.

M 1-1	1.0s	F: 50.0Hz	CF: 0.00	Memory	
Set		A: 0.00A	Ap: 0.0	Step	
3Ø4W:R	Phase	P: 0W	VA: 0	Edit	
		Q: 0VAR	PF: 0.000	<more>	
115.0 V		0.00 A			

When the System soft key is pressed the system parameter screen will open and show all the parameters available for editing. The screen will look as follows:

<b>Auto Run PROGRAM</b>		Loop Cycle	0	Λ	
Out Mode	AC	Result	LAST	V	
Function	3Ø4W	OC Fold	OFF	Edit	
PLC Remote	OFF	Lock	OFF	Exit	
Single Step	OFF	Mem Lock	ON		
Alarm	5	Volt Sense	INT		
Contrast	5	Sync Signal	OFF		
Power Up	OFF				



If the system parameters are set to MANUAL Mode, the screen will look as follows:





<b>Auto Run MANUAL</b>		F Lo-Lmt	40.0Hz	Λ	
Out Mode	AC	Start Angle	0°	V	
Alarm	5	End Angle	0°	Edit	
Contrast	5	Result	LAST	Exit	
Power UP	OFF	OCaFold	OFF		
V Hi-Lmt	300.0V	Transient	OFF		
V Lo-Lmt	0.0V	Lock	OFF		
F Hi-Lmt	1000Hz	<more>			

<b>Mem Lock ON</b>			Λ	
Volt Sense	INT		V	
Sync Signal	EVENT		Edit	
			Exit	

Use the , soft keys to navigate through the System parameters. Press the Edit soft key to select the parameter. The parameter will be highlighted black if it is available for editing. Press the Edit soft key to open up the system parameter for editing. The Exit soft key will return you back to the set screen. If you open any System parameter screen you can navigate through the System parameters by using the Prev and Next soft keys.

#### 4.3.1 Editing Auto Run Mode

Use the  ,  soft keys to navigate to the Auto Run parameter. Pressing the Edit soft key will provide the following screen:



Auto Run = <b>PROGRAM</b>	Prev	
Auto Run Mode: PROGRAM / MANUAL	Next	
	Change	
	Exit	


Auto Run = indicates the status of the run mode that is programmed into the instrument.

Auto Run Mode: indicates the run mode that can be programmed into the instrument.

Press the Change soft key to toggle the Auto Run Mode to PROGRAM / MANUAL / IEC61000-4-11. To save the parameter, press the Enter soft key. To cancel the editing of the Auto Run Mode, press the Esc soft key. When the Enter soft key is pressed the Auto Run Mode is accepted and you transition into the next system parameter: Out Mode.

#### 4.3.2 Editing Out Mode

Use the  ,  soft keys to navigate to the Out Mode parameter. Pressing the Edit soft key will provide the following screen:



Out Mode = <b>AC</b>	Prev	
Output Mode: AC / DC	Next	
	Change	
	Exit	

Out Mode = indicates the instrument is configured to output AC or DC voltage.

Output Mode: indicates the output mode that can be programmed into the instrument.

Press the Change soft key to toggle the Out Mode to AC or DC. To save the parameter, press the Enter soft key. To cancel the editing of the Out Mode, press the Esc soft key. When the Enter soft key is pressed the Out Mode is accepted and you transition into the next system parameter: Single Step.

#### 4.3.3 Editing Single Step (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Single Step parameter. Pressing the Edit soft key will provide the following screen:

Single Step = <b>ON</b>	Prev	<input type="text"/>
Single Step Mode:	Next	<input type="text"/>
ON = TEST for next step.	Change	<input type="text"/>
OFF = Run all steps.	Exit	<input type="text"/>

Single Step = indicates the status of the single step mode that is programmed into the instrument.

Single Step Mode: indicates the single step mode that can be programmed into the instrument.

Press the Change soft key to toggle the Single Step Mode to ON/OFF. To save the parameter, press the Enter soft key. To cancel the editing of the Single Step Mode, press the Esc soft key. When the Enter soft key is pressed the Single Step Mode is accepted and you transition into the next system parameter: Alarm.

#### 4.3.4 Editing Alarm

Use the  ,  soft keys to navigate to the Alarm parameter. Pressing the Edit soft key will provide the following screen:

Alarm = <b>5</b>	Prev	<input type="text"/>
Alarm Range:	Next	<input type="text"/>
0 - 9, 0=OFF, 9=High	Exit	<input type="text"/>

Alarm = indicates the status of the alarm volume that is programmed into the instrument.

Alarm Range: indicates the alarm range that can be programmed into the instrument.

Use the numeric keypad to enter in the alarm volume. Press the Enter soft key to accept the parameter. To cancel the editing of the alarm volume, press the Esc soft key. To move to the next system parameter for editing, press the Next or Prev soft key. The Exit soft key is also available to return to the System parameter screen. When the Enter soft key is pressed the Alarm volume is accepted and you transition into the next system parameter: Contrast.

#### 4.3.5 Editing Contrast

Use the  ,  soft keys to navigate to the Contrast parameter. Pressing the Edit soft key will provide the following screen:

Contrast = 5	Prev	<input type="button" value="←"/>
Contrast Range: 1 - 9,9=High	Next	<input type="button" value="→"/>
	Exit	<input type="button" value="Esc"/>

Contrast = indicates the status of the contrast setting that is programmed into the instrument.

Contrast Range: indicates the contrast range that can be programmed into the instrument.

Use the numeric keypad to enter in the contrast. The ranges available are 1 – 9, where 9 is the highest contrast or the darkest. Press the Enter soft key to accept the parameter. To cancel the editing of contrast setting, press the Esc soft key. To move to the next system parameter for editing, press the Next or Prev soft key. The Exit soft key is also available to return to the System parameter screen. When the Enter soft key is pressed the Contrast is accepted and you transition into the next system parameter: Power UP.

#### 4.3.6 Editing Power UP

Use the  ,  soft keys to navigate to the Power UP parameter. Pressing the Edit soft key will provide the following screen:

Power UP = OFF	Prev	<input type="button" value="←"/>
Power UP Mode:	Next	<input type="button" value="→"/>
ON = Output Voltage on at power up.	Change	<input type="button" value="↔"/>
OFF = Output voltage off at power up.	Exit	<input type="button" value="Esc"/>
LAST= Same as last power down.		

Power UP = indicates the power up mode that is programmed into the instrument.

Power UP Mode: indicates the power up mode that can be programmed into the instrument.

The power up modes available are ON, OFF or LAST. In the ON mode output will be supplied on power up of the instrument. In the OFF mode output will NOT be supplied on power up of the instrument. In the LAST mode output will be supplied according to the last state the instrument was in prior to power off.

Press the Change soft key to toggle the Power UP Mode to ON/OFF/LAST. To save the parameter, press the Enter soft key. To cancel the editing of the Power UP Mode press the Esc soft key. When the Enter soft key is pressed the Power UP Mode is accepted and you transition into the next system parameter.

#### 4.3.7 Editing Loop Cycle (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Loop Cycle parameter (only selectable for AC

output). Pressing the Edit soft key will provide the following screen:

Loop Cycle = <b>1</b>	Prev	<input type="button" value="←"/>
Loop Cycle Range: 0 - 9999 ,0=Cont. ,1=Off	Next	<input type="button" value="→"/>
	Exit	<input type="button" value="⏏"/>

Loop Cycle = indicates the number of loop cycles that will be performed when the output is active.

Loop Cycle Range: = indicates the selections available for the Loop Cycle Range.

The options available are 0 – 9999, 0=Cont., 1=Off. The 0 – 9999 selection programs the instrument to repeat the test cycle x number of times. The 0=Cont. selection indicates that the test loop will repeat in. The 1=Off selection indicates that the test loop will perform only one cycle. Use the numeric keypad to enter in the Loop Cycle Range. Press the Enter soft key to accept the parameter. To cancel the editing of Loop Cycle Range, press the Esc soft key. To move to the next system parameter for editing, press the Next or Prev soft key. The Exit soft key is also available to return to the System parameter screen. When the Enter soft key is pressed the Loop Cycle Mode is accepted and you transition into the next system parameter.

#### 4.3.8 Editing V Hi-Lmt & V Lo-Lmt (MANUAL Mode only)

Use the **←**, **→** soft keys to navigate to the V Hi-Lmt or V Lo-Lmt parameter. Pressing the Edit soft key will provide one of the following screens:

V Hi-Lmt = <b>300.0V</b>	Prev	<input type="button" value="←"/>
Voltage High Limit Range: 0.0 - 300.0V	Next	<input type="button" value="→"/>
	Exit	<input type="button" value="⏏"/>

V Hi-Lmt = indicates the voltage high limit that is programmed into the instrument.

Voltage High Limit Range: indicates the voltage range that can be programmed into the instrument.

V Lo-Lmt = <b>0.0V</b>	Prev	<input type="button" value="←"/>
Voltage Low Limit Range: 0.0 - 300.0V	Next	<input type="button" value="→"/>
	Exit	<input type="button" value="⏏"/>



V L-Lmt = indicates the voltage low limit that is programmed into the instrument.

Voltage Low Limit Range: indicates the voltage range that can be programmed into the instrument.

To change the voltage high limit or low limit use the numeric keypad and type the voltage value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the V Hi-Lmt or V Lo-Lmt parameter screen. When the Enter soft key is pressed the voltage is accepted and you transition into the next system parameter: Frequency Limit.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.9 Editing F Hi-Lmt & F Lo-Lmt (MANUAL Mode only)

Use the ,  soft keys to navigate to the F Hi-Lmt or F Lo-Lmt parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

<p>F Hi-Lmt = <span style="background-color: black; color: black;">1000Hz</span></p> <p>Frequency High Limit Range: 40.0 - 1000Hz</p>	<p>Prev </p> <p>Next </p> <p>Exit </p>
---	--

F Hi-Lmt = indicates the frequency high limit that is programmed into the instrument.  
Frequency High Limit Range: indicates the frequency range that can be programmed into the instrument.



<p>F Lo-Lmt = <span style="background-color: black; color: black;">40.0Hz</span></p> <p>Frequency Low Limit Range: 40.0 - 1000Hz</p>	<p>Prev </p> <p>Next </p> <p>Exit </p>
--	--





F Lo-Lmt = indicates the frequency low limit that is programmed into the instrument.  
Frequency Lo Limit Range: indicates the frequency range that can be programmed into the instrument

To change the frequency high limit or low limit use the numeric keypad and type the frequency value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the F Hi-Lmt or F Lo-Lmt parameter screen. When the Enter soft key is pressed the frequency is accepted and you transition into the next system parameter: Start and End Angle.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.





#### 4.3.10 Editing Start and End Angle (MANUAL Mode only)

Use the ,  soft keys to navigate to the Start Angle or End Angle parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

Start Angle =  0°	Prev 
Start Angle Range : 0 - 359°	Next 
	Exit 


Start Angle = indicates the start angle that is programmed into the instrument.

Start Angle Range: indicates the start angle range that can be programmed into the instrument.

End Angle =  0°	Prev 
End Angle Range : 0 - 359°	Next 
	Exit 



End Angle = indicates the end angle that is programmed into the instrument.

End Angle Range: indicates the end angle range that can be programmed into the instrument.

To change the start angle or end angle use the numeric keypad and type the degree value. Once you type in a number a shaded black box () will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Start Angle or End Angle parameter screen. When the Enter soft key is pressed the degree angle is accepted and you transition into the next parameter: Results.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.11 Editing Results

Use the ,  soft keys to navigate to the Results parameter. Pressing the Edit soft key will provide the following screen:

Results = <b>LAST</b>	Prev	<input type="text"/>
Result Mode:	Next	<input type="text"/>
ALL = View all steps	Change	<input type="text"/>
P/F = View full screen PASS or FAIL.	Exit	<input type="text"/>
LAST = View only last step.		

Results = indicates the results mode that is programmed into the instrument.

Results Mode: indicates the results mode that can be programmed into the instrument.

The Results Modes available are ALL, P/F, or LAST. The ALL mode will show all the testing results after the test is completed. The P/F mode will show only a pass/fail banner after the test is completed. The LAST mode will show only the last test or step that was performed when the test completes. Press the Change soft key to toggle the results mode to ALL, P/F, LAST. To save the parameter, press the Enter soft key. To cancel the editing of the Results Mode press the Esc soft key. When the Enter soft key is pressed the Results Mode is accepted and you transition into the next system parameter.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.12 Editing Transient (MANUAL Mode only)

Use the , soft keys to navigate to the Transient parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screens:

Transient = <b>OFF</b>	Prev	<input type="text"/>
Transient Mode:	Next	<input type="text"/>
ON = Enable the parameter in EDIT function.	Change	<input type="text"/>
OFF = Disable the parameter in EDIT function.	Exit	<input type="text"/>


Transient = indicates the Transient Mode that is programmed into the instrument.





Transient Mode: indicates the Transient Modes that can be programmed into the instrument.

The Transient Modes available are ON and OFF. Press the Change soft key to toggle the mode to ON or OFF. To save the parameter, press the Enter soft key. To cancel the editing of the Transient Mode press the Esc soft key. When the Enter soft key is pressed the Transient Mode is accepted and you transition into the next system parameter: Lock.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.13 Editing OC Fold

Use the  ,  soft keys to navigate to the OC Fold parameter. Pressing the Edit soft key will provide the following screens:

OC Fold = <b>ON</b> Over Current Fold Mode: ON = Enable Voltage fold back mode. OFF = Disable Voltage fold back mode.	Prev  Next  Change  Exit 
--	--



OC Fold = indicates the OC Fold Mode that is programmed into the instrument.





OC Fold Mode: indicates the OC Fold Mode that can be programmed into the instrument.

The OC Fold Modes available are ON and OFF. Press the Change soft key to toggle the mode to ON or OFF. To save the parameter, press the Enter soft key. To cancel the editing of the OC Fold Mode press the Esc soft key. When the Enter soft key is pressed the OC Fold Mode is accepted and you transition into the next system parameter: Transient.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.14 Editing Lock

Use the  ,  soft keys to navigate to the Lock parameter. Pressing the Edit soft key will provide the following screen:

Lock = <b>OFF</b> Lock Mode: ON = Keys are locked. OFF = Keys are not locked.	Prev  Next  Change  Exit 
--	--

Lock = indicates the security lock that is programmed into the instrument.

Lock Mode: indicates the lock mode that can be programmed into the instrument.

The Lock Modes available are ON and OFF. Press the Change soft key to toggle the mode to ON or OFF. To save the parameter, press the Enter soft key. To cancel the editing of the Lock Mode, press the Esc soft key. The level of security is determined by the Mem Lock function. When the Enter soft key is pressed the Lock Mode is accepted and you transition into the next system parameter: Mem Lock.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.15 Editing Mem Lock

Use the  ,  soft keys to navigate to the Mem Lock parameter. Pressing the Edit

soft key will provide the following screen:

Mem Lock = <b>ON</b> Mem Lock Mode: ON = Operator can not recall memries. OFF = Operator can recall memries.	Prev <input type="button" value=""/> Next <input type="button" value=""/> Change <input type="button" value=""/> Exit <input type="button" value=""/>
---	--

Mem Lock = indicates the security lock that is programmed into the instrument.

Mem Lock Mode: indicates the lock mode that can be programmed into the instrument.

The Mem Lock Modes available are ON and OFF. Press the Change soft key to toggle the mode to ON or OFF. To save the parameter, press the Enter soft key. To cancel the editing of the Mem Lock Mode, press the Esc soft key. The Mem Lock parameter will only initiate if Lock Mode is set ON. When the Enter soft key is pressed the Mem Lock Mode is accepted and you transition into the next system parameter: Volt Sense.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.16 Editing Volt Sense

Use the   soft keys to navigate to the Volt Sense parameter. Pressing the Edit soft key will provide the following screen:

Volt Sense = <b>INT</b> Voltage Sense Mode: INT = Select internal Voltage. EXT = Select external Voltage.	Prev <input type="button" value=""/> Next <input type="button" value=""/> Change <input type="button" value=""/> Exit <input type="button" value=""/>
--	--

Volt Sense = indicates the voltage sense that is programmed into the instrument.

Voltage Sense Mode: indicates the voltage sense mode that can be programmed into the instrument.

The Volt Sense Modes available are INT and EXT. Press the Change soft key to toggle the mode to INT or EXT. To save the parameter, press the Enter soft key. To cancel the editing of the Volt Sense Mode, press the Esc soft key. When the Enter soft key is pressed the Volt Sense Mode is accepted and you transition into the next system parameter: Sync Signal.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.17 Editing Ext Trig

Use the   soft keys to navigate to the Transient parameter (only selectable for

AC output). Pressing the Edit soft key will provide the following screens:

Ext Trig. = OFF	Prev	<input type="button" value=""/>
Ext Trig. Mode:	Next	<input type="button" value=""/>
OFF = Output Disabled.	Change	<input type="button" value=""/>
START = Output On Step Start.	Exit	<input type="button" value=""/>
END = Output On Step End.		
BOTH = Output On Step Start & End.		

Ext trig = indicates the Ext Trig that is programmed into the instrument.

Ext Trig Mode: indicates the Ext Trig mode that can be programmed into the instrument.

The Ext Trig Modes available are OFF, Start, END, and BOTH. Press the Change soft key to toggle the mode. To save the parameter, press the Enter soft key. To cancel the editing of the Ext Trig Mode, press the Esc soft key. When the Enter soft key is pressed the Ext Trig Mode is accepted and you transition into the next system parameter: Auto Run.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.3.18 Editing Function

Use the , soft keys to navigate to the Function parameter. Pressing the Edit soft key will provide the following screen:


Function = STEP17	Enter	<input type="button" value=""/>
Link Function Mode:	Change	<input type="button" value=""/>
1Ø2W = L-N.	Esc	<input type="button" value=""/>
3Ø4W = A-N & B-N & C-N @ 120°.		
1Ø3W = L1-N & L2-N @ 180°.		
Enter to save, Esc to cancel.		

Link Function Mode: indicates the Link Function mode that can be programmed into the instrument.


### 4.4 Using Memories and Steps (PROGRAM Mode only)

#### 4.4.1 Selecting a Memory

When in the Set screen use the soft keys <more> or <top> to navigate so the first soft key shows Memory.



Now press the Memory soft key and you will see the following screen:



Memory = will show you the current memory that is active.

Name = will list the name of the memory location. If a name hasn't been programmed for the memory location this will be blank as shown above.

The Memory Range: indicates the valid range you can select for this parameter screen. You can select 1 through 50 memory locations.

Two methods are available in selecting a memory.

1. Type in the memory number from the numeric keypad. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. You will also receive new text at the bottom of the display "Enter to save, Esc to cancel". To accept the data entry select the Enter soft key, or to cancel the data entry select the Esc soft key.



2. Press the List soft key to bring up a list of all programmed memories of the instrument. In order to get to the List soft key you will have to press the <more> soft key one time. The display will look as follows:

Memory = 1	Name	
Name = EXTECH	List	
Memory Range: 1 - 50		
	<top>	

Next you will press the List soft key to provide a list of memories programmed into the instrument. The screen will look as follows:

1 EXTECH	V	
2	Page ^	
3	Page v	
4		
5		
6		
7		
8	<more>	

Navigation through the memory list is handled by the soft, Page and Page soft keys. To select the memory list you must press the <more> soft key. The screen will look as follows:

1 EXTECH		
2		
3		
4		
5		
6		
7		
8		
	Load	
	Exit	
	<top>	

Now press the Load soft key, which will load the memory and bring you back to the set screen with the current memory and its parameters. If you press the Exit soft key you will be brought back to memory screen, and if you press the Exit soft key again you will go back to the set screen. The screen will look as follows:

M 3-1 20.0s F: 50.0Hz CF: 0.00	Memory	
Set A: 0.00A Ap: 0.0	Step	
P: 0Q VA: 0	Edit	
Q: 0VARPF: 0.000	<more>	
120.0 V		
0.00 A		

#### 4.4.2 Naming a Memory

To name a memory location you will need to press the <more> soft key when in the memory screen.

Memory = 1	Name	
Name = EXTECH	List	
Memory Range: 1 - 50	<top>	

Now press the Name soft key. This will bring you to the character map for entering the memory name. The numeric keypad is also available for creating a memory name. Press the <top> soft key to use the > soft key and soft key. Press the Select soft key to choose your characters. If you use the numeric keypad the character will be entered automatically when the keypad is pressed. To delete a character use the ← key on the numeric keypad. The memory name can not be longer than 10 characters. The screen will look as follows:

ABCDEFGHI JKLMNOPQR STUVWXYZ * _ ~ space	EXTECH	>	
		v	
		Select	
		<more>	

Now press the <more> soft key which will bring you to the following screen:

ABCDEFGHI JKLMNOPQR STUVWXYZ * _ ~ space	EXTECH	Enter	
		Esc	
Enter to save, Esc to cancel.		<top>	

To save the memory under the current name you selected via the character map / numeric keypad press the Enter soft key. This will bring you back to the set screen:

M 1-1	20.0s	F: 50.0Hz	CF: 0.00	Memory	
Set		A: 0.00A	Ap: 0.0	Step	
EXTECH		P: 0Q	VA: 0	Edit	
		Q: 0VARPF: 0.000		<more>	
120.0 V		0.00 A			

Pressing the Esc soft key versus the Enter soft key will bring you back to the main memory screen. The screen is as follows:

Memory = <b>1</b>	Name	<input type="text"/>
Name = EXTECH	List	<input type="text"/>
Memory Range: 1 - 50		<input type="text"/>
	<top>	<input type="text"/>

#### 4.4.3 Selecting a Step

To select a step press the Step soft key and the steps will sequence through. Each time the Step soft key is pressed the step will increase by one increment. There are 9 steps available. After the 9th step you will return to step number 1.

### 4.5 Test Parameters Description

It is important to note that any changes made within the Test Parameter screen will be associated with the individual memory and step location indicated on the display. These parameter settings when edited are not universal for each memory and step location. The operator must edit each individual memory location and step location if multiple test routines are required.

- 1. Start Angle (PROGRAM Mode only)** - provides the operator the flexibility to select the starting angle of the sine wave when the output voltage is generated. Start Angle is only selectable when the source is configured for AC output.
- 2. End Angle (PROGRAM Mode only)** - provides the operator the flexibility to select the ending angle of the sine wave when output voltage is terminated. End Angle is only selectable when the source is configured for AC output.
- 3. Memory Cycle (PROGRAM Mode only)** - gives the operator the flexibility to program how many times the memory test sequence will repeat when in the PROGRAM Mode. This eliminates the need for the operator to press the Test/Reset key or send multiple test commands to the source to repeat a memory test sequence.
- 4. Memory** - gives the operator the flexibility to change and edit the memory location (1-50).
- 5. Step (PROGRAM Mode only)** - gives the operator the flexibility to change and edit the step location (1 – 9).

6. **Voltage** - gives the operator the flexibility to edit the voltage output.
7. **Frequency** - gives the operator the flexibility to edit the frequency output. Frequency is only selectable when the source is configured for AC output.
8. **Transient (PROGRAM Mode only)** - gives the operator the flexibility to enable or disable the transient function. Note: Transient Mode simulates the effect of high speed voltage spikes and sags. For this reason, when Transient Mode is set to ON, test parameters 9 through 28 will no longer be displayed. Transient is only selectable when the source is configured for AC output.
9. **Ramp Up (PROGRAM Mode only)** - gives the operator the flexibility to increase the voltage output over a duration of time prior to achieving the programmed output voltage.
10. **Timer Unit (PROGRAM Mode only)** - determines the time increment that will be used for testing when the source is in PROGRAM Mode. The operator can select between Second/Minute/Hour.
11. **Delay (PROGRAM Mode only)** - gives the operator the flexibility to program a time delay, or warm up time. There is a voltage output present from the source, but the high and low limit thresholds are essentially ignored during this period.
12. **Dwell (PROGRAM Mode only)** - gives the operator the flexibility to program the actual test time. This time begins after the ramp up time has completed. The high and low limit thresholds are active once the delay time has completed.
13. **Ramp Down (PROGRAM Mode only)** - gives the operator the flexibility to program a time duration in which the output voltage is reduced to zero after the dwell time has completed.
14. **Step Cycle (PROGRAM Mode only)** - gives the operator the flexibility to program the number of looping cycles for a particular step. For example if the operator would like to have a step repeat five times the step cycle would be programmed to five. Step Cycle is only selectable when the source is configured for AC output.
15. **A Hi-Lmt (PROGRAM Mode)** - gives the operator the flexibility to program a maximum current threshold or ceiling level. When this level is reached a failure will occur.
16. **A Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum current threshold or floor level. If a minimum current level is not reached a

failure will occur. This insures a load is attached to the power source and there is a minimum current present.

**17. P Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum wattage threshold or ceiling level. When this level is reached a failure will occur.

**18. P Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum wattage threshold or floor level. If a minimum wattage level is not reached a failure will occur. This insures a load is attached to the power source and there is a minimum wattage present.

**19. Ap Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum peak current threshold or ceiling level. When this level is reached a failure will occur. Ap Hi-Lmt is only selectable when the source is configured for AC output.

**20. Ap Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum peak current threshold or floor level. If a minimum peak current level is not reached a failure will occur. This ensures a load is attached to the power source and there is a minimum peak current present. Ap Lo-Lmt is only selectable when the source is configured for AC output.

**21. CF Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum crest factor threshold or floor level. When this level is reach a failure will occur. CF Hi-Lmt is only selectable when the source is configured for AC output.

**22. CF Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum crest factor threshold or floor level. If a minimum crest factor level is not reached a failure will occur. CF Lo-Lmt is only selectable when the source is configured for AC output.

**23. PF Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum power factor threshold or ceiling level. When this level s reached a failure will occur. PF Hi-Lmt is only selectable is only selectable when the source is configured for AC output.

**24. PF Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum power factor threshold or floor level. If a minimum power factor level is not reached a failure will occur. This insures a load is attached to the power source and there

is a minimum power factor present. PF Lo-Lmt is only selectable when the source is configured for AC output.

**25. VA Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum apparent power threshold or floor level. When this level is reached a failure will occur. VA Hi-Lmt is only selectable when the source is configured for AC output.

**26. VA Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum apparent power threshold or floor level. If a minimum apparent power level is not reached a failure will occur. VA Lo-Lmt is only selectable when the source is configured for AC output.

**27. Q Hi-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a maximum reactive power threshold or floor level. When this level is reached a failure will occur. Q Hi-Lmt is only selectable when the source is configured for AC output.

**28. Q Lo-Lmt (PROGRAM Mode only)** - gives the operator the flexibility to program a minimum reactive power threshold or floor level. If a minimum reactive power level is not reached a failure will occur. Q Lo-Lmt is only selectable when the source is configured for AC output.

**29. Trans-Volt** - gives the operator the flexibility to program a surge or drop in the voltage output. Whether the voltage is a surge or a drop depends on the voltage that is programmed for this parameter. For example if the output voltage is programmed at 120 volts and the operator programs in a Trans-Volt of 150 volts this would be a surge of 30 volts. The opposite holds true; if the Trans-Volt is programmed at 90 volts this would be a drop of 30 volts. Trans- Volt is only selectable when the source is configured for AC output.

**30. Trans-Site** - gives the operator the flexibility to program the specific point in the sine wave to initialize the surge or the drop voltage. For example since a 60 Hz sine wave occurs 60 times per second, if the operator programs the Trans-Site for 8 milliseconds the surge or the drop voltage will occur at the halfway point (8 millisecond) of the sine wave or at the 180° point. Trans-Site is only selectable when the source is configured for AC output.

**31. Trans-Time** - gives the operator the flexibility to program the overall time duration of the surge or drop voltage. For example if the Trans-Site is 8 milliseconds; the output voltage is 120 volts; the surge voltage is 150 volts; and the Trans-Time is 20 milliseconds when the

sine wave reaches the 8 millisecond point (180°) the voltage will surge to 150 volts. This surge will hold for 20 milliseconds before the voltage output returns to 120 volts.

Trans-Time is only selectable when the source is configured for AC output.

**32. Trans-Cycle** - gives the operator the flexibility to program whether the transient voltage will occur continuously for each size wave of the test routine. The operator has the choice of selecting 0 or 1-9999. Trans-Cycle is only selectable when the source is configured for AC output.

**33. Phase Set (Option)** - gives the operator the flexibility to adjust the hi- and lo-limits for all phases during 1Ø3W and 3Ø4W modes. Selecting L1-N will allow the operator to set the limits for the instrument providing L1-N output voltage. Selecting L2-N will allow the operator to set the limits for the instrument providing the L2-N output voltage. Selecting L3-N will allow the operator to set the limits for the instrument providing the L3-N output voltage. Limits must be set for each phase in all steps (PROGRAM mode only).

**34. Prompt (PROGRAM Mode only)** - gives the operator the flexibility to program a message unique to a particular step. The message will be shown on the LCD graphic display prior to the test beginning for that particular step test routine. At this point the test routine will be interrupted and the operator must press the Test/Reset key to begin the test sequence.



**35. Connect (PROGRAM Mode only)** - gives the operator the flexibility to program whether one step will be linked or connected to another step. For example in order to link step one to step two, the Connect parameter must be turned ON. Steps can only be connected in sequential order.

## 4.6 Editing Test Parameters

To edit testing parameters press the Edit soft key from the set screen. The following screen will be displayed if the system parameters are set to PROGRAM Mode:

Start Angle	0°	Ramp Up	0.0s		
End Angle	0°	Timer Unit	SECOND	^	
Memory Cycle	1	Delay	0.5s	v	
Memory	1	Dwell	0.5s		
Step	1	Ramp Down	0.0s	Edit	
Voltage	100.0V	Step Cycle			
Frequency	60.0Hz	A Hi-Lmt	0.00A	Exit	
Transient	OFF	<more>			

A Lo-Lmt	0.00A	PF Lo-Lmt	0.000		
P Hi-Lmt	0W	VA Hi-Lmt	0VA	^	
P Lo-Lmt	0W	VA Lo-Lmt	0VA	v	
Ap Hi-Lmt	0.0A	Q Hi-Lmt	0VAR		
Ap Lo-Lmt	0.0A	Q Lo-Lmt	0VAR	Edit	
CF Hi-Lmt	0.00	Prompt			
CF Lo-Lmt	0.00	Connect	OFF	Exit	
PF Hi-Lmt	0.000				

Use the  ,  soft keys to navigate to the testing parameter that will be changed. When you press the Edit soft key you will be moved to the specific parameter screen for editing. If you press the Exit soft key you will be brought back to the set screen.



If the Transient parameter is turned OFF you will not see the testing parameters for Trans-Volt, Trans-Site, Trans-Time, and Trans-Cycle. If the Transient parameter is turned ON you will not see the testing parameters for Ramp Up, Timer Unit, Delay, Dwell, Ramp Down, Step Cycle, A Hi-Lmt, A Lo-Lmt, P Hi-Lmt, P Lo-Lmt, Ap Hi-Lmt, Ap Lo-Lmt, CF Hi-Lmt, CF Lo-Lmt, PF Hi-Lmt, PF Lo-Lmt, VA Hi-Lmt, VA Lo-Lmt, Q Hi-Lmt, and Q Lo-Lmt.

If the system parameters are set to MANUAL Mode the following display will be shown:



Memory	1		^	
Voltage	132.0V		v	
Frequency	60.0Hz			
A Hi-Lmt	0.00A		Edit	
			Exit	

If the system parameters are set to MANUAL Mode and the Transient parameter is turned ON, the following display will be shown:

Memory	1		^	
Voltage	100.0V		v	
Frequency	50.0Hz			
Trans-Volt	100.0V		Edit	
Trans-Site	0.0ms			
Trans-Time	0.5ms		Exit	
Trans-Cycle	1			

Use the  ,  soft keys to navigate to the testing parameter that will be changed. When you press the Edit soft key you will be moved to the specific parameter screen for editing. If you press the Exit soft key you will be brought back to the set screen.





#### 4.6.1 Editing Start and End Angle (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Start Angle or End Angle parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

Start Angle = 	Prev 
Start Angle Range: 0 - 359°	Next 
	Exit 

Start Angle = indicates the start angle that is programmed into the instrument.

Start Angle Range: indicates the start angle range that can be programmed into the instrument.

End Angle = 	Prev 
End Angle Range: 0 - 359°	Next 
	Exit 

End Angle = indicates the end angle that is programmed into the instrument.

End Angle Range: indicates the end angle range that can be programmed into the instrument.

If you edit the start angle or end angle on a particular step, all 9 steps in that memory location will automatically be set to the same start angle and end angle. If several steps are connected together to form a sequence of tests, the start angle will apply to the first step in the sequence and the end angle will apply to the last step in that sequence.



If memories are connected together as part of a test sequence, the start angle will apply to the first step in the sequence and the end angle will apply to the last step in the sequence. For example, memory 1 step 7 is linked to memory 1 step 8, memory 1 step 9 and memory 2 step 1 to create a four step sequence of tests.





If the start angle is set to 90 degrees and the end angle is set to 180 degrees, the output voltage waveform at memory 1 step 7 will have a start angle at 90 degrees and the output voltage waveform at memory 2 step 1 will end at a 180 degree angle.

To change the start angle or end angle use the numeric keypad and type the degree value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc soft key to move back to the Start Angle or End Angle parameter screen. When the Enter soft key is pressed the degree angle is accepted and you transition into the next parameter: Memory Cycle.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.


#### 4.6.2 Editing the Memory Cycle (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Memory Cycle parameter. Pressing the Edit soft key will provide the following screen:

Memory Cycle =  2	Prev 
Memory Cycle Range: 0 - 9999, 0=Cont, 1=OFF	Next 
	Exit 

Memory Cycle = indicates the number of cycles that will be performed when the output is active.



Memory Cycle Range: = provides the selections available for the Memory Cycle.

The options available are 0 – 9999, 0=Cont., 1=Off. The 0 – 9999 selection programs the instrument to repeat the test cycle x number of times. The 0=Cont. selection indicates that the test cycle will repeat in  . The 1=Off selection indicates that the test cycle will perform only one cycle.

To change the Memory Cycle, use the number keypad to select the memory cycle range and press the Enter soft key to accept the number. To cancel the editing of the Memory Cycle press, the Esc soft key. When the Enter soft key is pressed and the Memory Cycle is accepted, you transition into the next parameter: Memory.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.3 Editing the Memory (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Memory parameter. Pressing the Edit soft key will provide the following screen:

Memory = <b>1</b>	Prev	<input type="button" value=""/>
Name = EXTECH	Next	<input type="button" value=""/>
Memory Range: 1 - 50	Exit	<input type="button" value=""/>
	<more>	<input type="button" value=""/>

Refer to section 4.3.1 for editing the Memory. If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.4 Editing the Step (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Step parameter. Pressing the Edit soft key will provide the following screen:

Step = <b>1</b>	Prev	<input type="button" value=""/>
Step Range: 1 - 9	Next	<input type="button" value=""/>
	Exit	<input type="button" value=""/>

Step = indicates the step location within the memory.

Step Range: 1 – 9 indicates the step ranges available for selection.

To change the step, use the numeric keypad to select the step number and press the Enter soft key to accept the step. To cancel the editing of the step number, press the Esc soft key.

The Step parameter can also be edited from the set screen. If you hit the Step soft key, you can use the Step + and Step – soft keys to increase or decrease the step number.

When the Enter soft key is pressed and the Step is accepted you transition into the next parameter: Voltage.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.5 Editing Voltage

Use the  ,  soft keys to navigate to the Voltage parameter. Pressing the Edit soft key will provide the following screen:

Voltage = 110.0 V	Prev	<input type="button" value="←"/>
Voltage Range : 0.0 - 300.0	Next	<input type="button" value="→"/>
Voltage mode = AUTO	Change	<input type="button" value="↔"/>
Voltage mode : HIGH / AUTO	Exit	<input type="button" value="⏏"/>

Voltage = indicates the voltage currently programmed into the instrument.

Voltage Range: 0.0- 300 indicates the voltage range that can be programmed into the instrument.

Voltage Mode: indicates whether the instrument is in the Auto or High mode. Setting the Voltage mode to Auto, the system will automatically interpret the voltage range and switch to the high or low voltage output range. Setting the Voltage mode to High will put the output voltage into the high voltage output range and the current is limited to half as compared to the current limit in the low voltage output range. (Refer to the specification table in **3. Specifications and Controls** regarding current output based on voltage output range). Setting of voltage range may not influence the existing output voltage setting.

To change the voltage, use the numeric keypad and type the voltage. Once you type in a number a shaded black box ( ) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc soft key to move back to the voltage parameter screen. When the Enter soft key is pressed the voltage parameter is accepted and the system transitions into the next parameter: Frequency.

To change the Voltage mode from Auto to High press the Change soft key to toggle between the two selections. To accept the selection, press the Enter soft key. To cancel the selection, press the Esc soft key. You must press the Enter soft key to accept the range. To transition into the next parameter of frequency output you must press the Next soft key if you do not change the voltage setting.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.6 Editing Frequency

Use the , soft keys to navigate to the Frequency parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Frequency = 50.0Hz	Prev	
Frequency Range: 40.0 - 1000Hz	Next	
	Exit	

Frequency = indicates the frequency currently programmed into the instrument.

Frequency Range: 40.0 – 1000 Hz indicates the frequency range that can be programmed into the instrument.

To change the frequency, use the numeric keypad and type the frequency. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Frequency Parameter screen. When the Enter soft key is pressed the frequency is accepted and you transition into the next parameter: Transient.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.7 Editing Transient \* (PROGRAM Mode only)

Use the , soft keys to navigate to the Transient parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screens:

Transient = OFF	Prev	
Transient Mode:	Next	
ON = Enable the parameter in EDIT function.	Change	
OFF = Disable the parameter in EDIT function.	Exit	

Transient = indicates the Transient mode that is programmed into the instrument. Transient Mode: indicates the Transient mode that can be programmed into the instrument. The Transient modes available are ON and OFF. Press the Change soft key to toggle the mode to ON or OFF. To save the parameter, press the Enter soft key.



To cancel the editing of the Transient mode press, the Esc soft key. When the Enter soft key is pressed the Transient mode is accepted and you transition into the next parameter: Trans-Volt\*.




If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

\*If the Transient parameter is turned ON additional parameters of Trans-Volt, Trans-Site,

Trans-Time, and Trans-Cycle will be present in the Test Parameters screen.

#### 4.6.8 Editing Trans-Volt\* (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Trans-Volt parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Trans-Volt = <b>100.0V</b>	Prev 
Transient Voltage Range: 0.0 - 150.0V	Next 
	Exit 

Trans-Volt = indicates the Trans-Volt that is programmed into the instrument.



Transient Voltage Range: indicates the transient voltage range that can be programmed into the instrument.




To change the Transient voltage, use the numeric keypad and type the voltage. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the voltage, or press the Esc soft key to move back to the Trans-Volt parameter screen. When the Enter soft key is pressed the voltage is accepted and you transition into the next parameter: Trans-Site.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

\*Parameter is only available if the Trans parameter is turned ON.

#### 4.6.9 Editing Trans-Site\* (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Trans-Site parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Trans-Site = <b>0.0ms</b>	Prev 
Transient Site Range: 0.0 - 25.0ms	Next 
	Exit 

Trans-Site = indicates the transient site that is programmed into the instrument.

Transient Site Range: indicates the transient site range that can be programmed into the instrument.



To change the Transient site use the numeric keypad and type the time. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being





changed. Press the Enter soft key to accept the time, or press the Esc soft key to move back to the Trans-Site Parameter screen. When the Enter soft key is pressed the time is accepted and you transition into the next parameter: Trans-Time.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

\*Parameter is only available if the Transient parameter is turned ON.

#### 4.6.10 Editing Trans-Time\* (PROGRAM Mode only)

Use the ,  soft keys to navigate to the Trans-Time parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Trans-Time =  0.5ms	Prev 
Transient Pulse Width Range: 0.5 - 999.9ms	Next 
	Exit 



Trans-Time = indicates the Transient time that is programmed into the instrument.  
Transient Pulse Width Range: indicates the Transient pulse width range that can be programmed into the instrument.

To change the Transient pulse width use the numeric keypad and type the time. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the time, or press the Esc soft key to move back to the Trans-Time parameter screen. When the Enter soft key is pressed the time is accepted and you transition into the next parameter: Trans-Cont.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

\*Parameter is only available if the Transient parameter is turned ON.

#### 4.6.11 Editing Trans-Cycle\* (PROGRAM Mode only)

Use the ,  soft keys to navigate to the Trans-Cycle parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Trans-Cycle = <span style="background-color: black; color: black;">1</span>	Prev <input type="button" value="←"/>
Loop Cycle Range: 0 - 9999, 0=Constant	Next <input type="button" value="→"/>
	Exit <input type="button" value="X"/>

Trans-Cycle = indicates the Transient mode that is programmed into the instrument.


Transient Trig Mode: indicates the Transient trigger mode that can be programmed into the instrument.

If the Transient Trig mode is ON the transient parameters previously programmed will trigger automatically once the test starts. This will continue to be active until the Trig. soft key is pressed or a failure occurs. If the Transient Trig Mode is OFF the Transient parameter previously programmed will only trigger when the Trig. soft key is pressed.

For example, given the following parameters:

Parameter	Value
Output Voltage	100Vrms
Output Frequency	50 Hz
Transient Voltage	60Vrms
Transient Site	25ms
Transient Time	1ms

When the Trig. soft key is hit one time while the Trans-Cycle is set to OFF, the waveform will look like this:





When the Enter soft key is pressed the time is accepted and you transition into the next




parameter: Prompt

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

\*Parameter is only available if the Transient parameter is turned ON.

#### 4.6.12 Editing Ramp Up (PROGRAM Mode only)

Use the   soft keys to navigate to the Ramp Up parameter. Pressing the Edit soft key will provide the following screen:

Ramp Up = <b>0.0s</b>	Prev 
Ramp Up Time Range: 0.0 - 999.9s	Next 
	Exit 



Ramp Up = indicates the ramp up time that is programmed into the instrument.





Ramp Up Time Range: indicates the ramp up time range that can be programmed into the instrument.

To change the ramp up time, use the numeric keypad and type the time. Once you type in a number a shaded black box ( ) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the time, or press the Esc key to move back to the Ramp Up Time Parameter screen. When the Enter soft key is pressed the time is accepted and you transition into the next parameter: Timer Unit.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.13 Editing Timer Unit (PROGRAM Mode only)

Use the   soft keys to navigate to the Timer Unit parameter. Pressing the Edit soft key will provide the following screen:


Timer Unit = <b>SECOND</b>	Prev 
Timer Unit Mode: Second, Minute, or Hour	Next 
	Change 
	Exit 

Timer Unit = indicates the timer unit mode that is programmed into the instrument.

Timer Unit Mode: indicates the timer unit mode that can be programmed into the instrument.

The power up modes available are Second, Minute or Hour. Press the Change soft key to toggle the timer unit mode to Second/Minute/Hour. To save the parameter, press the Enter soft key. To cancel the editing of the Timer Unit Mode, press the Esc soft key. When the Enter soft key is pressed the Timer Unit Mode is accepted and you transition into the next parameter: Delay Time.

#### 4.6.14 Editing Delay (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Delay parameter. Pressing the Edit soft key will provide the following screen:

Delay =  0.5s	Prev 
Delay Time Range: 0.5 - 999.9s	Next 
	Exit 



Delay = indicates the delay time that is programmed into the instrument.





Delay Time Range: indicates the delay time range that can be programmed into the instrument.

To change the delay time, use the numeric keypad and type the time. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the time, or press the Esc soft key to move back to the Delay Time Parameter screen. When the Enter soft key is pressed, the time is accepted and you transition into the next parameter: Dwell.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.15 Editing Dwell (PROGRAM Mode only)

Use the  ,  soft keys to navigate to the Dwell parameter. Pressing the Edit soft key will provide the following screen:

Dwell =  0.5s	Prev 
Dwell Time Range: 0.5 - 999.9s, 0=Constant	Next 
	Exit 

Dwell = indicates the dwell time that is programmed into the instrument.

Dwell Time Range: indicates the dwell time range that can be programmed into the instrument.

To change the dwell time, use the numeric keypad and type the time. Once you type in a number a shaded black box ( ) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the time, or press the Esc soft key to move back to the Dwell Time Parameter screen. When the Enter soft key is pressed, the time is accepted and you transition into the next parameter: Ramp Down.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.16 Editing Ramp Down (PROGRAM Mode only)

Use the , soft keys to navigate to the Ramp Down parameter. Pressing the Edit soft key will provide the following screen:

Ramp Down = 0.0s	Prev	
Ramp Down Time Range: 0.0 - 999.9s	Next	
	Exit	

Ramp Down = indicates the ramp down time that is programmed into the instrument.

Ramp Down Time Range: indicates the ramp down time range that can be programmed into the instrument.

To change the ramp down time, use the numeric keypad and type the time. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the time, or press the Esc soft key to move back to the Ramp Down Time Parameter screen. When the Enter soft key is pressed the time is accepted and you transition into the next parameter: Step Cycle.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.17 Editing Step Cycle (PROGRAM Mode only)

Use the , soft keys to navigate to the Step Cycle parameter (only selectable for AC output). Pressing the Edit soft key will provide the following screen:

Step Cycle = 1	Prev	
Step Cycle Range: 0 - 9999, 0=Cont, 1=OFF	Next	
	Exit	

Step Cycle = indicates the step cycle that is programmed into the instrument.

Step Cycle Range: indicates the step cycle range that can be programmed into the instrument.

The ranges available are 0 – 9999, 0=Cont., 1=Off. The 0 – 9999 selection programs the instrument to repeat the test step cycle x number of times. The 0=Cont. selection indicates that the test cycle will repeat in . The 1=Off selection indicates that the test cycle will perform only one cycle. When the “Enter” soft key is pressed the step cycle is accepted and you transition into the next parameter: A Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.18 Editing A Hi-Lmt & A Lo-Lmt (PROGRAM Mode only)

Use the , soft keys to navigate to the A Hi-Lmt or Lo-Lmt parameter. Pressing the Edit soft key will provide one of the following screens:

A Hi-Lmt = 0.00A	Prev
Current High Limit Range: 0.00 - 9.20A, 0=OFF	Next
	Exit

A Hi-Lmt = indicates the current high limit that is programmed into the instrument. Current High Limit Range: indicates the current range that can be programmed into the instrument. If you select the 0=OFF a high limit current range is turned OFF. The editing of the A Hi-Lmt parameter is available in the PROGRAM and MANUAL Mode.

A Lo-Lmt = 0.00A	Prev
Current Low Limit Range: 0.00 - 9.20A	Next
	Exit



A Lo-Lmt = indicates the current low limit that is programmed into the instrument. Current Low Limit Range: indicates the current range that can be programmed into the instrument. The A Lo-Lmt parameter setting is only available in the PROGRAM Mode.





To change the current high limit or low limit, use the numeric keypad and type the current value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc soft key to move back to the Current Parameter screen. When the Enter soft key is pressed the current is accepted and you transition into the next parameter: P Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press

the Prev or Next soft key.

#### 4.6.19 Editing P Hi-Lmt & P Lo-Lmt (PROGRAM Mode only)

Use the ,  soft keys to navigate to the P Hi-Lmt or P Lo-Lmt parameter. Pressing the Edit soft key will provide one of the following screens:

P Hi-Lmt =  0 W	Prev 
Power High Limit Range: 0 - 1000W, 0=OFF	Next 
	Exit 

P Hi-Lmt = indicates the power high limit that is programmed into the instrument.

Power High Limit Range: indicates the power range that can be programmed into the instrument. If you select the 0=OFF a high limit power range is turned OFF.

P Lo-Lmt =  0 W	Prev 
Power Low Limit Range: 0 - 1000W	Next 
	Exit 



P Lo-Lmt = indicates the power low limit that is programmed into the instrument.





Power Low Limit Range: indicates the power range that can be programmed into the instrument.

To change the Power High Limit or Low Limit, use the numeric keypad and type the power value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Power Parameter screen. When the Enter soft key is pressed the power is accepted and you transition into the next parameter: Ap Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.20 Editing Ap Hi-Lmt & Ap Lo-Lmt (PROGRAM Mode only)

Use the ,  soft keys to navigate to the Ap Hi-Lmt or Ap Lo-Lmt parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

Ap Hi-Lmt =  0.0 A	Prev 
Peak Current High Limit Range: 0.0 - 36.8A, 0=OFF	Next 
	Exit 

Ap Hi-Lmt = indicates the peak current high limit that is programmed into the instrument.

Peak Current High Limit Range: indicates the peak current range that can be programmed into the instrument. If you select the 0=OFF a high limit peak current range is turned OFF.

Ap Lo-Lmt = 0.0A	Prev	
Peak Current Low Limit Range: 0.0 - 36.8A	Next	
	Exit	

Ap Lo-Lmt = indicates the peak current low limit that is programmed into the instrument.  
Peak Current Low Limit Range: indicates the peak current range that can be programmed into the instrument.

To change the Peak Current High Limit or Low Limit use the numeric keypad and type the peak current value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Peak Current Parameter screen. When the Enter soft key is pressed the peak current is accepted and you transition into the next parameter: CF Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.21 Editing CF Hi-Lmt & CF Lo-Lmt (PROGRAM Mode only)

Use the , soft keys to navigate to the CF Hi-Lmt or CF Lo-Lmt parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

CF Hi-Lmt = 0.00	Prev	
Crest Factor High Limit Range: 0.00 - 10.00, 0=OFF	Next	
	Exit	

CF Hi-Lmt = indicates the crest factor high limit that is programmed into the instrument.  
Crest Factor High Limit Range: indicates the crest factor range that can be programmed into the instrument. If you select the 0=OFF high limit crest factor range is turned OFF.


CF Lo-Lmt = 0.00	Prev	
Crest Factor Low Limit Range: 0.00 - 10.00, 0=OFF	Next	
	Exit	




CF Lo-Lmt = indicates the crest factor low limit that is programmed into the instrument.  
Crest Factor Low Limit Range: indicates the crest factor range that can be programmed into the instrument.

To change the Crest Factor High Limit or Low Limit use the numeric keypad and type the peak current value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Crest Factor Parameter screen. When the Enter soft key is pressed the crest factor is accepted and you transition into the next parameter: PF Hi-Lmt.




If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.22 Editing PF Hi-Lmt & PF Lo-Lmt (PROGRAM Mode only)

Use the  soft keys to navigate to the PF Hi-Lmt or PF Lo-Lmt parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

PF Hi-Lmt = 0.000	Prev	
Power Factor High Limit Range: 0.000 - 1.000, 0=OFF	Next	
	Exit	

PF Hi-Lmt = indicates the power factor high limit that is programmed into the instrument.  
Power Factor High Limit Range: indicates the power factor range that can be programmed into the instrument. If you select the 0=OFF a high limit power factor range is turned OFF.

PF Lo-Lmt = 0.000	Prev	
Power Factor Low Limit Range: 0.000 - 1.000	Next	
	Exit	


PF Lo-Lmt = indicates the power factor low limit that is programmed into the instrument.  
Power Factor Low Limit Range: indicates the power factor range that can be programmed into the instrument.

To change the Power Factor High Limit or Low Limit use the numeric keypad and type the power factor value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Power Factor Parameter screen. When the Enter soft key is pressed the power factor is accepted and you transition into the next

parameter: VA Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.23 Editing VA Hi-Lmt & VA Lo-Lmt (PROGRAM Mode only)

Use the  soft keys to navigate to the VA Hi-Lmt or VA Lo-Lmt parameter (only selectable for AC output). Pressing the Edit soft key will provide one of the following screens:

VA Hi-Lmt =  0VA	Prev 
Apparent P High Limit Range: 0 - 1000VA, 0=OFF	Next 
	Exit 

VA Hi-Lmt = indicates the apparent power high limit that is programmed into the instrument.  
VA High Limit Range: indicates the apparent power range that can be programmed into the instrument. If you select the 0=OFF apparent power range is turned OFF.

VA Lo-Lmt =  0.00	Prev 
Apparent P Low Limit Range: 0 - 1000VA, 0=OFF	Next 
	Exit 

VA Lo-Lmt = indicates the apparent power low limit that is programmed into the instrument.  
VA Low Limit Range: indicates the apparent power range that can be programmed into the instrument.

To change the Apparent Power High Limit or Low Limit use the numeric keypad and type the peak current value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Apparent Power Parameter screen. When the Enter soft key is pressed the apparent power is accepted and you transition into the next parameter: Q Hi-Lmt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.24 Editing Q Hi-Lmt & Q Lo-Lmt (PROGRAM Mode only)

Use the  soft keys to navigate to the Q Hi-Lmt or Q Lo-Lmt parameter (only selectable

for AC output). Pressing the Edit soft key will provide one of the following screens:

Q Hi-Lmt = <span style="background-color: black; color: black;">0 VAR</span>	Prev <span style="background-color: black; color: black;">  </span>
Reactive P High Limit Range: 0 - 1000VAR, 0=OFF	Next <span style="background-color: black; color: black;">  </span>
	Exit <span style="background-color: black; color: black;">  </span>

Q Hi-Lmt = indicates the reactive power high limit that is programmed into the instrument.

Reactive Power High Limit Range: indicates the reactive power range that can be programmed into the instrument. If you select the 0=OFF reactive power high limit range is turned OFF.

Q Lo-Lmt = <span style="background-color: black; color: black;">0 VAR</span>	Prev <span style="background-color: black; color: black;">  </span>
Reactive P Low Limit Range: 0 - 1000VAR, 0=OFF	Next <span style="background-color: black; color: black;">  </span>
	Exit <span style="background-color: black; color: black;">  </span>

Q Lo-Lmt = indicates the reactive power low limit that is programmed into the instrument.

Reactive Power Low Limit Range: indicates the reactive power range that can be programmed into the instrument.

To change the Reactive Power High Limit or Low Limit use the numeric keypad and type the peak current value. Once you type in a number a shaded black box (■) will begin blinking acknowledging the parameter is being changed. Press the Enter soft key to accept the parameter, or press the Esc key to move back to the Reactive Power Parameter screen. When the Enter soft key is pressed the peak current is accepted and you transition into the next parameter: Prompt.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.25 Editing Prompt

Use the    ,    soft keys to navigate to the Prompt parameter. Pressing the Edit soft key will provide the following screen:

ABCDEFGHI JKLMNOPQR STUVWXYZ * - _ ~ <span style="background-color: black; color: black;">space</span>	Prompt = <span style="background-color: black; color: black;">  </span>	Prev <span style="background-color: black; color: black;">  </span>
		Next <span style="background-color: black; color: black;">  </span>
		Edit <span style="background-color: black; color: black;">  </span>
		Exit <span style="background-color: black; color: black;">  </span>

Press the “Edit” soft key and a blinking shaded black box (■) will appear notifying you that characters can be inserted into the prompt field. Use the soft keys > and v to highlight the character you would like to use. Press the Select soft key to accept the character. You can also use the numeric keypad to enter characters. When the numeric keypad is used the number is inserted automatically and the Select soft key is not needed. To delete a character use the Backspace key <- - located on the numeric keypad. There are 32 characters spaces available for the prompt message. To save the prompt message press the <more> soft key which will bring you to the following screen.

ABCDEFGHI JKL MN O ■ PQR STUVWXYZ * - _ ~ space	Prompt = STOP	> v Select <more>	
--	------------------	----------------------------	--

Press the Enter soft key to accept the prompt message. To cancel the prompt message, press the Esc soft key. When the Enter soft key is pressed the prompt is accepted and you transition into the next parameter: Step Cycle.

If you wish to bypass editing this parameter and move to the next parameter you can press the Prev or Next soft key.

#### 4.6.26 Editing Connect

Use the , soft keys to navigate to the Connect parameter. Pressing the Edit soft key will provide the following screen:

Connect = OFF  Step Connect Mode : ON / OFF	Prev Next Change Exit	
---	--------------------------------	--

Connect = indicates the status of the connect mode that is programmed into the instrument.  
 Step Connect Mode: indicates the connect mode that can be programmed into the instrument.

Press the Change soft key to toggle the connect mode ON/OFF. To save the parameter, press the Enter soft key. To cancel the editing of the step mode press the Esc soft key. When the Enter soft key is pressed the connect mode is accepted and you transition into the next parameter: Memory Cycle.

If you wish to bypass editing this parameter and move to the next parameter you can press

the Prev or Next soft key.

When the connect mode is ON there will be an underscore \_ next to the step number in the set screen. It will look as follows:

M 1- <u>1</u>	20.0s	F: 50.0Hz	CF: 0.00	Memory	
Set		A: 0.00A	Ap: 0.0	Step	
		P: 0Q	VA: 0	Edit	
		Q: 0VARPF: 0.000		<more>	
100.0 V		0.00 A			

#### 4.6.27 Editing Phase Set

Use the , soft keys to navigate to the Phase Set parameter. Pressing the Edit soft key will provide the following screen:

Phase Set = T	Prev	
Phase Setting Mode:	Next	
R = Set Phase R Hi&Lo Limits.	Change	
S = Set Phase S Hi&Lo Limits.	Exit	
T = Set Phase T Hi&Lo Limits.		

Phase Set = indicates the Phase Setting mode for operating two instruments in a master-slave configuration.

Phase Setting Mode: indicates the Phase Setting mode that can be programmed into the instrument.

#### 4.7 Reviewing Test Results

To review the testing results press the Result soft key in the set screen. You may have to use the <more> soft key to get to the Results soft key. The screen will look as follows when you are in the correct screen:

M 1-1	20.0s	F: 50.0Hz	CF: 0.00	Result	
Set		A: 0.00A	Ap: 0.0	System	
		P: 0Q	VA: 0		
		Q: 0VARPF: 0.000		<top>	
120.0 V		0.00 A			

Press the Result soft key to view the results. The screen will look as follows:

1-1 P	Pass		√	
	Settings	Results	Page ^	
	120.0V	120.0V	Page v	
	50.0Hz	50.0Hz		
	0W	0W		
	0.00A	0.000A		
	0.0Ap	0.0Ap	Exit	

If you have multiple steps linked together you will have to use the navigation soft keys in order to toggle through each step to review the results. Press the Exit soft key to move back to the set screen.

## CHAPTER 5. Test Modes

### 5.1 Description of Test Modes

Within the System Parameter settings of Auto Mode you have two selections available (PROGRAM/MANUAL).

The PROGRAM Mode will run your testing routine according to the parameters that have been entered within the testing parameters screen when the TEST/RESET key is pressed. In most cases there will be a testing time associated with the test mode unless the time has been selected to  $\infty$  or the cycle mode is ON.

The MANUAL Mode will run your testing routine according to the parameters currently programmed into the instrument when the Test/Reset key is pressed. However, there is no test time associated with the MANUAL Mode. The output is continuous until the Test/Reset key is pressed again.

### 5.2 Initializing a Test in PROGRAM Mode

#### 5.2.1 AC Output

When the AUTO RUN parameter in the System Parameters menu is set to PROGRAM Mode the Set screen will be displayed as follows:

M 1-1	0.0s	F: 50.0Hz	CF: 0.00	Memory	<input type="checkbox"/>
Set		A: 0.00A	Ap: 0.0	Step	<input type="checkbox"/>
		P: 0Q	VA: 0	Edit	<input type="checkbox"/>
		Q: 0VARPF: 0.000		<more>	<input type="checkbox"/>
120.0 V		0.00 A			


To initialize the test press the Test/Reset key and the LED for the key will illuminate. The text "Set" on the set screen will turn to Dwell, in addition your soft keys will change to include Meter, Cycle, Keypad, and Trig\*.

\*Only available if Transient parameter is set to OFF.

M 1-1	20.6s	F: 50.0Hz	CF: 0.00	Meter	<input type="checkbox"/>
Dwell		A: 0.00A	Ap: 0.0	Cycle	<input type="checkbox"/>
		P: 0Q	VA: 0		<input type="checkbox"/>
		Q: 0VARPF: 0.000		Keypad	<input type="checkbox"/>
120.0 V		0.00 A			

If you press the Meter soft key a shaded black box (■) will highlight the meter parameters of F:, A:, P:, Q:, CF:, Ap, VA:, PF:, and the display will read the output on the on the right side of the display. Every time the meter key is pressed it will toggle through the meter parameters.

If you press the Cycle soft key the display will change and provide you the cycle information from Step, Memory, and Loop. This will take the place of the meter reading on the right side of the display. To move back to the meter reading, press the Meter soft key.




If you press the Keypad soft key the display will show the text Voltage = above the voltage meter on the left hand side of the display. A shaded black box (■) will be flashing waiting for a voltage value to be entered from the numeric keypad. Once the value has been typed into the instrument you must press the Enter soft key to accept the value. The Esc soft key is available to exit out of this mode and move back to the test screen.

When the test cycle has completed the display will show you the meter readings and the soft keys will change to Meter, Cycle, Exit. You can toggle through the meter displays or show the cycles by pressing the appropriate soft keys. The display will also show you the test status where the text “Dwell” was located. If the test passes you will see Pass. If you press the Exit soft key the screen will reset back to the set screen.

### 5.2.2 DC Output

When the AUTO RUN parameter in the System Parameters menu is set to PROGRAM Mode the Set screen will be displayed as follows:




To initialize the test press the Test/Reset key and the LED for the key will illuminate. The text “Set” on the set screen will turn to Dwell, in addition your soft keys will change to include Meter and Keypad. The output will run continuously until the Test/Reset key is pressed again, or there is a failure condition.

When the RESET key is pressed or a Hi-Limit failure occurs, the instrument DC output voltage

has a fixed 1 second ramp down discharge time. The Test/Reset LED flashes during this ramp down period to indicate the output is still active.

If you press the Meter soft key a shaded black box (■) will highlight the meter parameters P: or A: and the display will read the output on the right side of the display. Every time the meter key is pressed it will toggle between the two meter parameters.




If you press the Keypad soft key the display will show the text Voltage = above the voltage meter on the left hand side of the display. A shaded black box (■) will be flashing waiting for a voltage value to be entered from the numeric keypad. Once the value has been typed into the instrument you must press the Enter soft key to accept the value. The Esc soft key is available to exit out of this mode and move back to the test screen.


## 5.3 Initializing a Test in MANUAL Mode

### 5.3.1 AC Output

When the AUTO RUN parameter in the System Parameters is set to the MANUAL Mode the Set screen will be displayed as follows:



To initialize the test press the Test/Reset key and the LED for the key will illuminate. The text “Set” on the set screen will turn to Dwell, in addition your soft keys will change to include Meter, AUTO, Trig. and Keypad In the MANUAL Mode output will run continuously until the Test/Reset key is pressed again, or there is a failure condition.



If you press the Meter soft key a shaded black box (■) will highlight the meter parameters of F:, A:, P:, Q:, CF:, Ap:, VA:, PF:, and the display will read the output on the on the right side of

the display. Every time the meter key is pressed it will toggle through the meter parameters.

If you press the AUTO soft key a shaded black box (■) will toggle between AUTO & HIGH. The AUTO Mode will toggle the voltage range from low to high based on the voltage setting. This allows you to receive maximum current based on the voltage range you have selected. If the HIGH Mode is selected the current will always be at 50% of the maximum capacity of the instrument at any voltage level selected whether it would be in the low or high range.


If you press the Keypad soft key the display will show the text Voltage = above the voltage meter on the left hand of the display. A shaded black box (■) will be flashing waiting for a voltage value to be entered from the numeric keypad. Once the value has been typed into the instrument you must press the Enter soft key to accept the value. The Esc soft key is available to exit out of this mode and move back to the test screen.

In the MANUAL Mode the Rotary Knob on the front panel also becomes active. It can be used to adjust voltage or frequency. When the instrument is in an idle state, it can also be used to edit the Hi-Lmt. To adjust the frequency with the Rotary Knob the meter selection must be on F. To adjust the voltage with the Rotary Knob the meter can be on any selection except F. To adjust the Hi-Lmt with the Rotary Knob the meter selection must be on Hi-Lmt. To adjust the output, rotate the knob either clockwise or counterclockwise. Clockwise rotations will increase the output, whereas counterclockwise rotations will decrease the output. If LOCK is set to ON, the Rotary Knob is disabled.

If you press the Trig. soft key you will hear a beep which is notification that the trigger has been activated for the Transient parameters that have been entered into the instrument.

### 5.3.2 DC Output

When the AUTO RUN parameter in the System Parameters menu is set to MANUAL Mode the Set screen will be displayed as follows:




To initialize the test press the Test/Reset key and the LED for the key will illuminate. The text "Set" on the set screen will turn to Dwell, in addition your soft keys will change to include Meter and Keypad. The output will run continuously until the Test/Reset key is pressed again, or there is a failure condition.

When the RESET key is pressed or a Hi-Limit failure occurs, the instrument DC output voltage

has a fixed 1 second ramp down discharge time. The Test/Reset LED flashes during this ramp down period to indicate the output is still active.

If you press the Meter soft key a shaded black box (■) will highlight the meter parameters P: or A: and the display will read the output on the right side of the display. Every time the meter key is pressed it will toggle between the two meter parameters.



If you press the Keypad soft key the display will show the text Voltage = above the voltage meter on the left hand side of the display. A shaded black box (■) will be flashing waiting for a voltage value to be entered from the numeric keypad. Once the value has been typed into the instrument you must press the Enter soft key to accept the value. The Esc soft key is available to exit out of this mode and move back to the test screen.

The Rotary Knob on the front panel also becomes active. To adjust the voltage rotate the knob either clockwise or counterclockwise. Clockwise rotations will increase the voltage, whereas counterclockwise rotations will decrease the voltage. If LOCK is set to ON, the Rotary Knob is disabled.

## CHAPTER 6. Displayed Messages

During any abnormal conditions, there are several error messages that could be indicated in the display. When an abnormal condition occurs the output will disable and the alarm will sound. The Test/Reset LED indicator will also begin flashing. Pressing the Test/Reset key will reset the audible alarm and the abnormal condition will be displayed.

### **WARNING**

All error messages occur in abnormal conditions and therefore must be recorded. Check the cause of the error to ensure the problem is eliminated before restarting

the operation, or contact Associated Power Technologies, Inc., or our official distributors for further assistance.

Display Message	Definition
OTP	Over Temperature Protection
OCP	Over Current Protection
OPP	Over Power Protection
OVP	Output Voltage Protection
A-SH	Amplifier Shutdown Protection
RCP	Reverse Current Protection
LVP	Low Voltage Protection

### 6.1 OTP – Over Temperature Protection

Displayed if the heat sink of the instrument has exceeded 130° C. The voltage and current displays will show the overloaded voltage or current respectively. The LED indicator for the Test/Reset key will be blinking.

### 6.2 OCP – Over Current Protection

Displayed if the output current has exceeded 110% of maximum current rating for 1 second or there is a short circuit for 6 seconds. The LED indicator for the Test/Reset key will be blinking.

### 6.3 OPP – Over Power Protection

Displayed if the output power has exceeded 110% of maximum power rating for 1 second. The LED indicator for the Test/Reset key will be blinking.

### 6.4 OVP – Output Voltage Protection

Displayed if the output voltage has exceeded 5 V of the setting voltage in the 0-150V range, or has exceeded 10 V of the setting voltage in the 0-300V range.

The LED indicator for the Test/Reset key will be blinking.

If an OVP error occurs on the next power up cycle on the displays will show Volt Err.

### **6.5 A-SH – Amplifier Shutdown Protection**

Displayed if the amplifier is in an abnormal condition. The LED indicator for the Test/Reset key will be blinking.

### **6.6 RCP – Reverse Current Protection**

Displayed if the power source detects negative current feeding back into the source. RCP will trip when negative power exceeds 75W of the instrument's full power. The LED indicator the Test/Reset key will be blinking.

### **6.7 LVP – Low Voltage Protection**


Displayed if the power source detects a discrepancy between the output voltage setting of 10V or greater for more than 1 sec. The LED indicator the Test/Reset key will be blinking.

## CHAPTER7. Remote PLC

### 7.1 Signal Output

The rear panel connector of the EAC series provides output signals to remotely monitor PASS, FAIL, and PROCESSING conditions via a 9-Pin D-type connector. When a terminal becomes active the relay closes thereby allowing the external voltage to operate an external device. The following table provides the conditions of each pin and the relay state.

Condition	Pins	Relay State
PASS	Connection between PIN1 & PIN 2	Closes on PASS and is opened on next test initialized
FAIL	Connection between PIN3 & PIN 4	Closes on FAIL and is opened when next test is initialized
PROCESSING	Connection between PIN5 & PIN 6	Closes when test initialized and opens after test is completed



### 7.2 Signal Input - 7 Memory Recall

**The EAC series** also provides an optional remote input interface to control any test operation via remote. The 9-Pin D-Type connector signals for Test, Reset, and 7 Memories (M1 – M7) input control signals. PLC remote functions will be activated once the PLC Remote from the System setup Parameter is turned on. Upon turning on the PLC Remote setting, the TEST/RESET LED will be lit and the buzzer will beep twice before returning to the RESET condition, when any key on the front panel is pressed. Whenever there is an abnormal output detected the instrument can be reset by pressing the TEST/RESET key or the initializing a reset through the PLC remote.


The following table provides the conditions of each pin and the relay state:

Condition	Pins	Relay State
TEST	Connection between PIN 3 & PIN5	Momentary contact closure
RESET	Connection between PIN 2 & PIN5	Momentary contact closure

### Memory Input Control

Selection of up to 7 memory locations is achieved by using a Normally Open (N.O) Momentary Button. The truth table below provides the pin locations needed in order to select the memories.

Memory	PIN 1	PIN 9	PIN 8
M1	OFF	OFF	ON
M2	OFF	ON	OFF
M3	OFF	ON	ON
M4	ON	OFF	OFF
M5	ON	OFF	ON
M6	ON	ON	OFF
M7	ON	ON	ON



## CHAPTER 8. Bus Remote Interface GPIB/RS-232


This section provides information on the proper use and configuration of bus remote interface. The RS-232 remote interface is standard on model **EAC series** but the GPIB (IEEE-488) interface option can be substituted for the RS-232 interface. Please refer to the Option section of this manual for details on the EAC series options. The RS-232 interface also uses the same command set as the GPIB interface for setting of test parameters. However there are many functions of the GPIB 488.2 interface that are not available through RS-232. The IEEE-488 interface included with the EAC series conforms to the requirements of the IEEE-488.2 standard.

### 8.1 RS-232 Interface

This interface is standard on the **EAC series**. This interface provides all of the control commands and parameter setting commands of the GPIB interface with the exception of the 488.2 Common Command the Status Reporting commands and SRQ capability. All commands can be found in the command list, section 12.9 of this manual. The identification command \*IDN is also available through RS-232.

#### 8.1.1 RS-232 Connector

The RS-232 connection is configured as follows for a 9 pin Serial Port Interface.



#### 8.1.2 Communication Port Configuration

The COM port should have the following configuration:

- 9600 baud
- 8 data bits
- No polarity
- 1 stop bit

This interface does not support XON/XOFF protocol and any hardware handshaking. The controller should be configured to ignore the Handshaking Lines DTR (PIN 4), DSR (PIN 6) and RTS (PIN 9). If the port cannot be configured through software to ignore the lines, the handshaking lines should then be jumped together in two different sets. The PIN 4 and 6 jumped together while PIN 7 & 8 jumped together at the controller end of the cable.

### 8.1.3 Sending and Receiving Commands

#### Sending Commands

When sending commands over the RS-232 bus the instrument will send a response string of 06 Hex or 6 decimal and Acknowledge (ACK) ASCII control code if the transfer was recognized and completed by the instrument. If there is an error with the command string that is sent, the instrument will respond with 15 Hex or 21 decimal and the Not Acknowledge (NAK) ASCII code. The ACK or NAK response allows for software handshaking in order to monitor and control data flow.

#### Receiving Commands

When requesting data from the instrument it will automatically send the data back to the controller input buffer. The controller input buffer will accumulate the data being sent from the instrument including the ACK and NAK response strings, until the controller has read it. When the strings or command has been sent it must be terminated with LF=(0AH), such as "TEST"+LF.

## 8.2 GPIB Interface

### 8.2.1 GPIB Connector

Connection is usually accomplished with a 24-conductor cable with a plug on one end and a connector at the other end. Devices may be connected in a linear, star or a combination configuration.

The standard connector is the Amphenol or Cinch Series 57 Microribbon or AMP CHAMP type. The GPIB uses negative logic with standard transistor-transistor logic (TTL) levels. When DAV is true, for example, it is a TTL low level ( 0/8 V), and when DAV is false, it is a TTL high level ( 2.0 V).

#### Restrictions and Limitations on the GPIB

- A maximum separation of 4 m between any two devices and an average separation of 2 m over the entire bus.
- A maximum total cable length of 20 m.
- No more than 15 device loads connected to each bus, with no less than two thirds powered on. For example 1 GPIB controller and a maximum of 14 GPIB instruments.
- **Note:** A bus extender, which is available from numerous manufacturers, is available to overcome these limitations.

### 8.2.2 GPIB Address

Each device on the GPIB (IEEE-488) interface must have a unique address. You can set the address of the 620L to any value between 0 and 30. The address can only be set from the front panel. The address is stored in non-volatile memory and does not change when the power has been off or after a remote reset.

The address is set to 8 when the instrument is shipped from the factory.

## 8.3 Interface Functions

The capability of a device connected to the bus is specified by its interface functions. These functions provide the means for a device to receive, process, and send messages over the bus. The interface functions are listed in the chart below.

### GPIB 488.1 INTERFACE FUNCTIONS

Interface Function	Subset	Description
Source Handshake	SH1	Complete Source handshake capability
Acceptor Handshake	AH1	Complete Acceptor handshake capability
Talker	T6	Talker functions (unaddress if MLA)
Listener	L4	Listener functions (unaddress if MTA)
Service Request	SR1	Complete Service request capability
Remote Local	RL0	No remote/local capability
Parallel Poll	PP0	No parallel poll capability
Device Clear	DC1	Complete Device clear capability
Device Trigger	DT0	No device trigger capability
Controller	C0	No controller capability
Electrical Interface	E2	Three-state drivers

Controllable Items	Test and Reset control.
	Setting of test parameters for tests.
	Reading of instrument status and test results.
Data Codes	ASCII
Delimiter	NL (+ EOI)

## 8.4 GPIB/RS-232 Interface Command List

A GPIB read command must be sent after the command strings, to retrieve any data from a query command (?). The **EEC EAC series** GPIB bus will not send any data to the controller without being queried. The RS-232 bus will automatically send any response back to the controller's input buffer. Each command string should be terminated the ASCII control code, New Line <NL>, OAh or the end of line EOL message for GPIB.

The following conventions are used to describe the commands syntax. Braces { } enclose each parameter for a command string. Triangle brackets (< >) indicate that you must substitute a value for the enclosed parameter. The Pipe ( | ) is used to separate different parameter options for a command. Do not include any of the above characters when sending the commands. The command and the value should be separated with a space.

All commands that end with a question mark (?) are query commands and required an IEEE-488 read command to retrieve the data from the device's output buffer.

### 8.4.1 Basic Commands and Query Commands

The following commands are used to control actual output voltage and current from the instrument. This command set also includes query commands. These query commands will retrieve data from the instrument. The GPIB bus application requires an IEEE-488 read command to be sent after the query command. These commands include functions for retrieving test data, test results and metering values.

#### AC Basic Command

Command	Description	AC Program mode	AC Manual mode	unit
TEST	TEST	Power On		
RESET	RESET	Power Off		
TD?	Testing meters data	Memory,Step,Status,Freq, q,Volt,Curr,Power,APeak, PF,Q,CF,VA,Timer	Memory,Status,Freq, Volt,Curr,Power,APeak, PF,Q,CF,VA	
RD XX?	Results meters data			
TDFREQ?	Testing frequency meter	40.0~1000		Hz
TDVOLT?	Testing voltage meter	0.0~300.0		V
TDCURR?	Testing current meter	See Note1-1	See Note1-1	A
TDAP?	Testing current peak meter	See Note4		A
TDP?	Testing power meter	See Note3-1		W
TDPF?	Testing PF meter	0.000~1.000		

TDQ?	Testing Q meter	See Note3-1		
TDCF?	Testing CF meter	0.00~10.00		
TDVA?	Testing VA meter	See Note3-1		
TDTIMER?	Testing timer meter	0.0~999.9	-	s/m/h
METER X	SELECT METER X	X=0-8,0=F,1=A,2=P,	X=0-7,0=F,1=A,2=P,3=	
METER?	SELECT METER?	3=Q,4=CF,5=AP,6=VA,7=PF,8=CYCLE	Q,4=CF,5=AP,6=VA,7=PF	
SDTRG	TRANSIENT TRIGGER	-	Trigger one time TRANSIENT	
STEP CYCLE?	STEP CYCLE?	0~9999	-	
MEMORY CYCLE?	MEMORY CYCLE?	0~9999	-	
LOOP CYCLE?	LOOP CYCLE?	0~9999	-	
RR?	READ:RESET?	See Note5		
RI?	READ:INTERLOCK?	0~1, 0=CLOSE,1=OPEN		
EXTP	EXT TRIGGER pulse	Trigger one pulse on SYNC		

## DC Basic Command

Command	Description	DC Program mode	DC Manual mode	unit
TEST	TEST	Power On		
RESET	RESET	Power Off		
TD?	Testing meters data	Memory,Step,Status,	Memory,Status,	
RD XX?	Results meters data	Volt,Curr,Power,Timer	Volt,Curr,Power	
TDVOLT?	Testing voltage meter	0.0~420.0		V
TDCURR?	Testing current meter	See Note2-1	See Note2-1	A
TDP?	Testing power meter	See Note3-1		W
TDTIMER?	Testing timer meter	0.0~999.9	-	s/m/h
METER X	SELECT METER X	X=1,2,8	X=1,2	
METER?	SELECT METER?	1=A,2=P,8=CYCLE	1=A,2=P	
STEP CYCLE?	STEP CYCLE?	0~9999	-	
MEMORY CYCLE?	MEMORY CYCLE?	0~9999	-	
LOOP CYCLE?	LOOP CYCLE?	0~9999	-	
RR?	READ:RESET?	See Note5		
RI?	READ:INTERLOCK?	0~1, 0=CLOSE,1=OPEN		
EXTP	EXT TRIGGER pulse	Trigger one pulse on SYNC		

## **TEST**

Turns on the output voltage at the selected step loaded into memory.

## **RESET**

Turns the output voltage off or resets the instrument in the event of a failure.

101

## **TD?**

Read the active data being displayed on the LCD display while the test is in process. Will also read the last data taken when the test sequence has completed. Each parameter is separated by commas and includes memory number, step number, test status, frequency value, voltage value, current value, power value, peak current value, power factor value and timer metering. The syntax for the command response is {memory, step, status, frequency, voltage, current, power, peak current, power factor, timer}. Each meter will contain only the value and not the units. Current and peak current are displayed in amps while power is displayed in Watts.

## **RD <step number>?**

Read the results for an individual step. The step number is the actual step number that has been saved within the file, not the order of which the steps were executed. For example if the test was executed starting from step 3 and ending with step 5 then the first step test results will be found in location 3 not in location 1. Each parameter is separated by commas and includes step number, test type, test status, and metering. The syntax for this command response is {memory, step, status, frequency, voltage, current, power, peak current, power factor, timer}. Each meter will contain only the value and not the units. Each meter will contain only the value and not the units. Current and peak current are displayed in amps while power is displayed in Watts.

## **TDFREQ?**

Read the active frequency value being displayed while a test is in process.

## **TDVOLT?**

Read the active voltage value being displayed while a test is in process.

## **TDCURR?**

Read the active current value being displayed while a test is in process.

## **TDAP?**

Read the active peak current value being displayed while a test is in process.

**TDP?**

Read the active power value being displayed while a test is in process.

**TDPF?**

Read the active power factor value being displayed while a test is in process.

**TDQ?**

Read the active reactive current value being displayed while a test is in process.

**TDCF?**

Read the active crest factor value being displayed while a test is in process.

**TDVA?**

Read the active apparent power value being displayed while a test is in process.

**TDTIMER?**

Read the active timer meter value being displayed while a test is in process.

**METER {4|3|2|1|0}**

Selects the metered value that is displayed while a test is in process. 4 sets the meter = power factor, 3 sets the meter = current, 2 sets the meter = power, 1 sets the meter = peak current and 0 sets meter = frequency.

**METER?**

Read the selected meter value. Returns value of 0 – 4.

**SDTRG**

Triggers a one shot surge/drop in order to simulate loading or brown out conditions.

**STEPCYCLE?**

Read the value of the current step cycle signal. When the step cycle has been activated the query will return a value of 0 for continuous, 1 for Off or a range from 0~9999 cycles.

**MEMORYCYCLE?**

Read the value of the current memory cycle signal. When the memory cycle has been activated the query will return a value of 0 for continuous cycling, 1 for Off or a range from 0~9999 cycles.

**LOOPCYCLE?**

Read the value of the current loop cycle signal. When the loop cycle has been activated the query will return a value of 0 for continuous cycling, 1 for Off or a range from 0~9999 cycles.

#### RR?

Read the remote reset input signal. When the remote reset has been activated by closing the contacts the query will return a value of 1 to indicate the instrument is being reset.

#### RI?

Read the remote Interlock input signal. When the remote Interlock has been activated by opening the contacts the query will return a value of 0 to indicate the instrument is in the Interlock state and will not be able to generate output voltage or current.

#### EXTP

External trigger pulse.

### 8.4.2 3 Ø 4W Queries

The following commands are used to query the instrument while in Polyphase mode.

COMMAND	EEC R/S/T (3Ø4W)	AC Program mode	AC Manual mode	unit
TDRFREQ?	Testing frequency meter	40.0~1000		Hz
TDRVOLT?	Testing voltage meter	0.0~300.0		V
TDRCURR?	Testing current meter	See Note1-1		A
TDRAP?	Testing current peak meter	See Note4		A
TDRP?	Testing power meter	See Note3-1		W
TDRPF?	Testing pf meter	0.000~1.000		
TDRQ?	Testing Q meter	See Note3-1		
TDRCF?	Testing CF meter	0.00~10.00		
TDRVA?	Testing VA meter	See Note3-1		VAR
TDSFREQ?	Testing frequency meter	40.0~1000		Hz
TDSVOLT?	Testing voltage meter	0.0~300.0		V
TDSCURR?	Testing current meter	See Note1-1		A
TDSAP?	Testing current peak meter	See Note4		A
TDSP?	Testing power meter	See Note3-1		W
TDSPF?	Testing pf meter	0.000~1.000		

TDSQ?	Testing Q meter	See Note3-1	
TDSCF?	Testing CF meter	0.00~10.00	
TDSVA?	Testing VA meter	See Note3-1	VAR
TDTFREQ?	Testing frequency meter	40.0~1000	Hz
TDTVOLT?	Testing voltage meter	0.0~300.0	V
TDTCURR?	Testing current meter	See Note1-1	A
TDTAP?	Testing current peak meter	See Note4	A
TDTP?	Testing power meter	See Note3-1	W
TDTPF?	Testing pf meter	0.000~1.000	
TDTQ?	Testing Q meter	See Note3-1	
TDTCF?	Testing CF meter	0.00~10.00	
TDTVA?	Testing VA meter	See Note3-1	VAR
TDEVOLT?	Testing voltage meter	0.0~300.0	V
TDECURR?	Testing current meter	See Note1-1	A
TDEP?	Testing power meter	See Note3-1	W
TDEPF?	Testing pf meter	0.000~1.000	
TDEQ?	Testing Q meter	See Note3-1	
TDEVA?	Testing VA meter	See Note3-1	VAR
TDR?	Testing RØ meter data	Memory,Step,Status, Freq,Volt,Curr, Power,APeak, PF,Q,CF,VA,Timer	Memory,Status, Freq,Volt,Curr, Power,APeak, PF,Q,CF,VA
TDS?	Testing SØ meter data		
TDT?	Testing TØ meter data		
TDE?	Testing ΣØ meter data		
RDR XX?	Results RØ meter data		
RDS XX?	Results SØ meter data		
RDT XX?	Results TØ meter data		
RDE XX?	Results ΣØ meter data		

### TDA?

Read the selected Phase A meter values while a test is in process. Query only available in AC Program mode and AC Manual mode.

### TDB?

Read the selected Phase B meter values while a test is in process. Query only available in AC Program mode and AC Manual mode.

### TDC?

Read the selected Phase C meter values while a test is in process. Query only available in AC Program mode and AC Manual mode.

#### **TDE?**

Read the total (Phase A + B + C) meter values while a test is in process. Query only available in AC Program mode and AC Manual mode.

#### **RDA XX?**

Read the selected Phase A results once a test has completed. Query only available in AC Program mode and AC Manual mode.

#### **RDB XX?**

Read the selected Phase B results once a test has completed. Query only available in AC Program mode and AC Manual mode.

#### **RDC XX?**

Read the selected Phase C results once a test has completed. Query only available in AC Program mode and AC Manual mode.

#### **RDE XX?**

Read the selected total (Phase A + B + C) results once a test has completed. Query only available in AC Program mode and AC Manual mode.

### **8.4.3 1 Ø 3W Queries**

The following commands are used to query the instrument while in Parallel mode.

COMMAND	L1-N / L2-N( 1Ø3W)	AC Program mode	AC Manual mode	unit
TDL1FREQ?	Testing frequency meter	40.0~1000		Hz
TDL1VOLT?	Testing voltage meter	0.0~300.0		V
TDL1CURR?	Testing current meter	See Note1-1		A
TDL1AP?	Testing current peak meter	See Note4		A
TDL1P?	Testing power meter	See Note3-1		W
TDL1PF?	Testing pf meter	0.000~1.000		
TDL1Q?	Testing Q meter	See Note3-1		
TDL1CF?	Testing CF meter	0.00~10.00		
TDL1VA?	Testing VA meter	See Note3-1		VAR
TDL2FREQ?	Testing frequency meter	40.0~1000		Hz
TDL2VOLT?	Testing voltage meter	0.0~300.0		V
TDL2CURR?	Testing current meter	See Note1-1		A

TDL2AP?	Testing current peak meter	See Note4	A
TDL2P?	Testing power meter	See Note3-1	W
TDL2PF?	Testing pf meter	0.000~1.000	
TDL2Q?	Testing Q meter	See Note3-1	
TDL2CF?	Testing CF meter	0.00~10.00	
TDL2VA?	Testing VA meter	See Note3-1	VAR
TDL1L2VOLT?	Testing voltage meter	0.0~300.0	V
TDL1L2CURR?	Testing current meter	See Note1-1	A
TDL1L2P?	Testing power meter	See Note3-1	W
TDL1L2PF?	Testing pf meter	0.000~1.000	
TDL1L2Q?	Testing Q meter	See Note3-1	
TDL1L2VA?	Testing VA meter	See Note3-1	VAR
TDL1N?	Testing L1-N meter data	Memory,Step,Status, Freq,Volt,Curr, Power,APeak, PF,Q,CF,VA,Timer	Memory,Status, Freq,Volt,Curr, Power,APeak, PF,Q,CF,VA
TDL2N?	Testing L2-N meter data		
TDL1L2?	Testing L1-L2 meter data		
RDL1N XX?	Results L1-N meter data		
RDL2N XX?	Results L2-N meter data		
RDL1L2 XX?	Results L1-L2 meter data		

#### **TDL1N?**

Read the selected L1-N meter values while a test is in process.

#### **TDL2N?**

Read the selected L2-N meter values while a test is in process.

#### **TDL1L2?**

Read the selected total (L1-L2) meter values while a test is in process.

#### **RDL1N XX?**

Read the selected L1-N results once a test has completed.

#### **RDL2N XX?**

Read the selected L2-N results once a test has completed.

#### **RDL1L2 XX?**

Read the total (L1-L2) results once a test has completed.

#### 8.4.4 Program Commands and Companion Queries

These commands are used to modify individual test parameters within each step. Many of these commands require a parameter value to be included with the command. The companion query command will read the parameter. The writing of the parameter requires that the unit not be included with the value, only the numeric value should be included with the command. Also, when the query commands are sent, the response will not include the unit characters.

#### AC mode parameter setting

Command	Description	AC Program mode	AC Manual mode	unit
NAME XXXX	MEMORY NAME XXXX	XXXX=1~10 BYTES		
NAME?	MEMORY NAME?			
SAG XXXX	START ANGLE XXXX	XXXX=0-359	-	°
SAG?	START ANGLE?	0-359	-	°
EAG XXXX	END ANGLE XXXX	XXXX=0-359	-	°
EAG?	END ANGLE?	0-359	-	°
MC XXXX	MEMORY CYCLE XXXX	XXXX=0~9999 ,0=Continue ,1=OFF	-	
MC?	MEMORY CYCLE?	0-9999	-	
MEMORY X	MEMORY X	X=1-50		
MEMORY?	MEMORY?	1-50		
STEP X	STEP X	X=1-9	-	
STEP?	STEP?	1-9	-	
VOLT XXXX	VOLTAGE XXX.X	XXXX=0.0~300.0		V
VOLT?	VOLTAGE?	0.0~300.0		V
RANG X	RANG X	X=0-1, 0=HIGH,1=AUTO		
RANG?	RANG?	0-1		
FREQ XXXX	FREQUENCY XXXX	XXXX=40.0~1000		Hz
FREQ?	FREQUENCY?	40.0~1000		Hz
SD X	TRANSIENT X	X=0~1, 0=OFF,1=ON	-	
SD?	TRANSIENT?	0~1	-	
SDVOLT XXXX	TRANSIENT-VOLT XXXX	XXXX=0.0~300.0		V
SDVOLT?	TRANSIENT-VOLT?	0.0~300.0		V
SDLT XXX	TRANSIENT-SITE XXX	XXX=0~365		ms
SDLT?	TRANSIENT-SITE?	0~365		ms
SDHT XXXX	TRANSIENT-TIME XX.X	XXXX.X=0.5~999.9		ms
SDHT?	TRANSIENT-TIME?	0.5~999.9		ms

SDCT XXXX	TRANSIENT-CYCLE XXXX	X=0~9999, 0=CONT,1=OFF		
SDCT?	TRANSIENT-CYCLE?	0~9999		
RAMPUP XXXX	RAMP UP TIME XXXX	XXX.X=0.1~999.9	-	s
RAMPUP?	RAMP UP TIME?	0.1~999.9	-	s
TUNIT X	TIME UNIT X	X=0-2, 0=Second,1=Minute, 2=Hour	-	
TUNIT?	TIME UNIT?	0-2	-	
DELAY XXXX	DELAY TIME XXXX	XXX.X=0.1~999.9	-	s/m/h
DELAY?	DELAY TIME?	0.1~999.9	-	s/m/h
DWELL XXXX	DWELL TIME XXXX	XXXX=0.0~999.9 ,0=Const	-	s/m/h
DWELL?	DWELL TIME?	0.0~999.9	-	s/m/h
RAMPDOWN XXX.X	RAMP DOWN TIME XXXX	XXX.X=0.1~999.9	-	s
RAMPDOWN?	RAMP DOWN TIME?	0.1~999.9	-	s
SC XXXX	STEP CYCLE XXXX	XXXX=0~9999 ,0=Cont,1=OFF	-	
SC?	STEP CYCLE?	0-9999	-	
PS X	PHASE SET X	See Note6		
PS?	PHASE SET?	See Note6		
AHI XXXX	A HI XXXX	See Note1-2	See Note1-2	A
AHI?	A HI?			A
ALO XXXX	A LO XXXX		-	A
ALO?	A LO?		-	A
PHI XXXX	POWER HI XXX.X	See Note3-2	-	W
PHI?	POWER HI?		-	W
PLO XXXX	POWER LO XXX.X		-	W
PLO?	POWER LO?		-	W
APHI XXX	AP HI XX.X	See Note4	-	A
APHI?	AP HI?		-	A
APLO XX.X	AP LO XX.X		-	A
APLO?	AP LO?		-	A
PFHI XXXX	PF HI X.XXX	XXXX=0.000~1.000	-	
PFHI?	PF HI?	0.000~1.000	-	
PFLO XXXX	PF LO XXXX	XXXX=0.000~1.000	-	
PFLO?	PF LO?	0.000~1.000	-	
CFHI XXXX	CF HI XX.XX	X.XX=0.00~10.00	-	
CFHI?	CF HI?	0.00~10.00	-	

CFLO XX.XX	CF LO XX.XX	X.XX=0.00~10.00	-	
CFLO?	CF LO?	0.00~10.00	-	
VAHI XXXX	VA HI XXXX	See Note3-2	-	
VAHI?	VA HI?		-	
VALO XXXX	VA LO XXXX		-	
VALO?	VA LO?		-	
QHI XXXX	Q HI XXXX	See Note3-2	-	VAR
QHI?	Q HI?		-	VAR
QLO XXXX	Q LO XXXX		-	VAR
QLO?	Q LO?		-	VAR
PTD	PROMPT DELETE		-	
PT XXXX	PROMPT XXXXXXXXXXXX	XXXX=1~30 BYTES	-	
PT?	PROMPT?		-	
CONNECT X	CONNECT X	X=0~1,0=OFF,1=ON	-	
CONNECT?	CONNECT?	0~1	-	
ET X	EXT TRIG X	X=0~3, 0=OFF,1=START, 2=END,3=BOTH	-	
ET?	EXT TRIG?	0~3	-	

### DC mode parameter setting

Command	Description	DC Program mode	DC Manual mode	unit
NAME XXXX	MEMORY NAME XXXX	XXXX=1~10 BYTES		
NAME?	MEMORY NAME?			
MC XXXX	MEMORY CYCLE XXXX	XXXX=0~9999 ,0=Continue ,1=OFF	-	
MC?	MEMORY CYCLE?	0-9999	-	
MEMORY X	MEMORY X	X=1-50		
MEMORY?	MEMORY?	1-50		
STEP X	STEP X	X=1-5	-	
STEP?	STEP?	1-5	-	
VOLT XXXX	VOLTAGE XXX.X	XXXX=0.0~400.0 or 0.0~200.0		V
VOLT?	VOLTAGE?	0.0~400.0 or 0.0~200.0		V
RANG X	RANG X	X=0-1, 0=HIGH,1=LOW		
RANG?	RANG?	0-1		
RAMPUP XXXX	RAMP UP TIME XXXX	XXX.X=0.1~999.9	-	s
RAMPUP?	RAMP UP TIME?	0.1~999.9	-	s

TUNIT X	TIME UNIT X	X=0-2, 0=Second,1=Minute, 2=Hour	-	
TUNIT?	TIME UNIT?	0-2	-	
DELAY XXXX	DELAY TIME XXXX	XXX.X=0.1~999.9	-	s/m/h
DELAY?	DELAY TIME?	0.1~999.9	-	s/m/h
DWELL XXXX	DWELL TIME XXXX	XXXX=0.0~999.9 ,0=Cons t	-	s/m/h
DWELL?	DWELL TIME?	0.0~999.9	-	s/m/h
RAMPDOWN XXX.X	RAMP DOWN TIME XXXX	XXX.X=0.1~999.9	-	s
RAMPDOWN?	RAMP DOWN TIME?	0.1~999.9	-	s
SC XXXX	STEP CYCLE XXXX	XXXX=0~9999 ,0=Cont,1= OFF	-	
SC?	STEP CYCLE?	0-9999	-	
AHI XXXX	A HI XXXX	See Note2-2	See Note2-2	A
AHI?	A HI?			A
ALO XXXX	A LO XXXX		-	A
ALO?	A LO?		-	A
PHI XXXX	POWER HI XXX.X	See Note3-2	-	W
PHI?	POWER HI?		-	W
PLO XXXX	POWER LO XXX.X		-	W
PLO?	POWER LO?		-	W
PTD	PROMPT DELETE		-	
PT XXXX	PROMPT XXXXXXXXXXXX	XXXX=1~30 BYTES	-	
PT?	PROMPT?		-	
CONNECT X	CONNECT X	X=0~1,0=OFF,1=ON	-	
CONNECT?	CONNECT?	0~1	-	
ET X	EXT TRIG X	X=0~3, 0=OFF,1=START, 2=END,3=BOTH	-	
ET?	EXT TRIG?	0~3	-	

#### 8.4.5 System Commands and Companion Queries

These commands are used to modify the system parameters for the instrument.

These commands require a parameter value to be included with the command.

The companion query command will read the parameter using the same value that is used for setting the parameter.

COMMAND	Panel Key Page	AC Program mode	AC Manual mode	DC Program mode	DC Manual mode	unit
---------	----------------	-----------------	----------------	-----------------	----------------	------

PLC X	PLC X	X=0~1, 0=OFF,1=ON				
PLC?	PLC?	0~1				
AR X	AUTO RUN X	X=0~2,0=PROGRAM,1=MANUAL,2=IEC61000-4-11				
AR?	AUTO RUN?	0~2				
OM X	OUT MODE X	X=0~1,0=AC,1=DC				
OM?	OUT MODE?	0~1				
SS X	SINGLE STEP X	X=0~1, 0=OFF,1=ON	-	X=0~1, 0=OFF,1=ON	-	
SS?	SINGLE STEP?	0~1	-	0~1	-	
ALARM X	ALARM X	X=0~9, 0=OFF,9=high				
ALARM?	ALARM?	0~9				
CONTRAST X	CONTRAST X	X=1~9, 9=high				
CONTRAST?	CONTRAST?	1~9				
PUP X	POWER UP X	X=0-2,0=OFF,1=ON,2=LAST				
PUP?	POWER UP?	0-2				
LC XXXX	LOOP CYCLE XXXX	XXXX=0~9999,0=Content,1=OFF	-	XXXX=0~9999,0=Content,1=OFF	-	
LC?	LOOP CYCLE?	0-9999	-	0-9999	-	
VHI XXXX	VOLT HI XXXX	-	XXXX=0.0~300.0	-	XXXX=0.0~420.0	V
VHI?	VOLT HI?	-	0.0~300.0	-	0.0~420.0	V
VLO XXXX	VOLT LO XXXX	-	XXXX=0.0~300.0	-	XXXX=0.0~420.0	V
VLO?	VOLT LO?	-	0.0~300.0	-	0.0~420.0	V
FHI XXXX	FREQ HI XXXX	-	XXXX=40.0~1000	-	-	Hz
FHI?	FREQ HI?	-	40.0~1000	-	-	Hz
FLO XXXX	FREQ LO XXXX	-	XXXX=40.0~1000	-	-	Hz
FLO?	FREQ LO?	-	40.0~1000	-	-	Hz
SAG XXX	START ANGLE XXX	-	XXXX=0-359	-	-	°
SAG?	START ANGLE?	-	0-359	-	-	°
EAG XXX	END ANGLE XXX	-	XXXX=0-359	-	-	°
EAG?	END ANGLE?	-	0-359	-	-	°
RESULTS X	RESULTS X	X=0-2, 0=ALL,1=P/F,2=LAST				°
RESULTS?	RESULTS?	0-2				°
OF X	OC Fold X	X=0~1, 0=OFF,1=ON				
OF?	OC Fold?	0~1				
SD X	TRANSIENT X	-	X=0~1,0=OFF,1=ON	-	-	
SD?	TRANSIENT?	-	0~1	-	-	
LOCK X	LOCK X	X=0~1, 0=OFF,1=ON				
LOCK?	LOCK?	0-1				

MEMLOCK X	MEMLOCK X	X=0~1, 0=OFF,1=ON			
MEMLOCK?	MEMLOCK?	0-1			
VS X	VOLT SENSE X	X=0~1, 0=INT,1=EXT			
VS?	VOLT SENSE?	0~1			
FUNCTION X	FUNCTION X	X=0~2, 0=1Ø2W, 1=3Ø4W, 2=1Ø3W	-	-	
FUNCTION?	FUNCTION?	0~2	-	-	
SSI X	SYNC SIGNAL X	X=0~2, 0=OFF,1=ON,2=EVENT,3=EXT			
SSI?	SYNC SIGNAL?	0~2			
IECITEM X	IEC ITEM X	X=0-1, 0=V-DIP, 1=V-VAR			
IECITEM?	IEC ITEM?	0~1			
IECRANG X	IEC RANG X	X=0-1, 0=HIGH, 1=LOW			
IECRANG?	IEC RANG?	0~1			
IECVOLT XXX.X	IEC VOLT XXX.X	XXXX=0.0~300.0			
IECVOLT?	IE CVOLT?	0.0~300.0			
IECFREQ X	IEC FREQ X	X=0-1, 0=50Hz, 1=60Hz			
IECFREQ?	IEC FREQ?	0~1			

Note1-1	Note2-1	Note3-1	Note4	Note5	Note6
FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = Low EAC-303=0.000-9.20 EAC-306=0.000-18.40  FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = High EAC-303=0.000-4.60 EAC-306=0.000-9.20  FUNCTION=1Ø2W Voltage Range = Low EAC-303=0.00-27.60 EAC-306=0.00-53.20  FUNCTION=1Ø2W Voltage Range = High EAC-303=0.00-13.80 EAC-306=0.00-27.60	Voltage Range = Low EAC-303=0.00-14.40 EAC-306=0.00-28.80  Voltage Range = High EAC-303=0.00-7.20 EAC-306=0.00-14.40	FUNCTION=3Ø4W FUNCTION=1Ø3W EAC-303=0.0-1000 EAC-306=0.0-2000  FUNCTION=1Ø2W OUT_MODE=DC EAC-303=0-3000 EAC-306=0-6000	FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = Low EAC-303=0.0-36.8 EAC-306=0.0-73.6  FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = High EAC-303=0.0-18.4 EAC-306=0.0-36.8  FUNCTION=1Ø2W Voltage Range = Low EAC-303=0.0-110.4 EAC-306=0.0-220.8  FUNCTION=1Ø2W Voltage Range = High EAC-303=0.0-55.2 EAC-306=0.0-110.4	When PLC Remote is ON 0~1, 0=CLOSE,1=OPEN	When test is running, select Phase page: FUNCTION=3Ø4W X=0-3, 0=AØ, 1=BØ,2=CØ,3=ΣØ FUNCTION=1Ø3W X=0-2, 0=L1-N, 1=L2-N, 2=L1-L2  When NO test, select Phase Set: FUNCTION=3Ø4W X=0-2, 0=AØ, 1=BØ,2=CØ FUNCTION=1Ø3W X=0-1, 0=L1-N, 1=L2-N

Note1-2	Note2-2	Note3-2
---------	---------	---------

FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = Low EAC-303=0,00-9.20 EAC-306=0,00-18.40	Voltage Range = Low EAC-303=0, 0.10-14.40 EAC-306=0, 0.10-28.80	FUNCTION=3Ø4W FUNCTION=1Ø3W EAC-303=0-1000 EAC-306=0-2000
FUNCTION=3Ø4W FUNCTION=1Ø3W Voltage Range = High EAC-303=0,00-4.60 EAC-306=0,00-9.20	Voltage Range = High EAC-303=0, 0.10-7.20 EAC-306=0, 0.10-14.40	FUNCTION=1Ø2W OUT_MODE=DC EAC-303=0-3000 EAC-306=0-6000
FUNCTION=1Ø2W Voltage Range = Low EAC-303=0, 0.10-27.60 EAC-306=0, 0.10-53.20		
FUNCTION=1Ø2W Voltage Range = High EAC-303=0, 0.10-13.80 EAC-306=0, 0.10-27.60		

#### 8.4.6 IEEE 488.2 Common Commands

These commands are required by the IEEE-488.2 standard with the exception of \*PSC, \*PSC?. Most of these commands are not available over the RS-232 bus except for the \*IDN? command which can be used to retrieve the instrument identification information, and the four status reporting commands \*ESR?, \*ESE, \*ESE? and \*STB?.

Command	Description	Acknowledgement
*IDN?	Identification Query	Company, Model Number, Serial Number, Firmware Revision
*RST	Reset Command	Reset U3
*TST?	Self-Test Query	00H=OK
		01H=TEST EEPROM ERROR
*CLS	Clear Status Command	Clear Standard Event Status Register
		Clear Service Request Register
*OPC	Operation Complete Command	When TEST command ok setting ESR BIT0 =1
*OPC?	Operation Complete Query	
*WAI	Wait for next command	
*ESR?	Standard Event Status Register Query	BIT 0 ,01H, (1)      Operation Complete
		BIT 1 ,02H, (2)      Not Used
		BIT 2 ,04H, (4)      Query Error
		BIT 3 ,08H, (8)      Device Error
		BIT 4 ,10H,(16)      Execution Error
		BIT 5 ,20H,(32)      Command Error
		BIT 6 ,40H,(64)      Not Used

		BIT 7 ,80H,(128) Power On
*ESE value	Standard Event Status Enable Command	value=0~255
*ESE?	Standard Event Status Enable Query	0 - 255
*STB?	Read Status Byte Query	BIT 0 ,01H,(1) ALL PASS
		BIT 1 ,02H,(2) FAIL
		BIT 2 ,04H,(4) ABORT
		BIT 3 ,08H,(8) PROCESS
		BIT 4 ,10H,(16) Message Available
		BIT 5 ,20H,(32) Standard Event (ESB)
		BIT 6 ,40H,(64) Request Service (MSS)
		BIT 7 ,80H,(128) PROMPT
*SRE value	Service Request Enable Command	value=0~255
*SRE?	Service Request Enable Query	0 - 255
*PSC value	Power-On Status Command	value=0/1
*PSC?	Power-On Status Query	0, 1

#### **\*IDN?**

Read the instrument identification string. Company = EEC.

#### **\*RST**

Reset the instrument to original power on configuration. Does not clear Enable register for Standard Summary Status or Standard Event Registers. Does not clear the output queue. Does not clear the power-on-status-clear flag.

#### **\*TST?**

Performs a self test of the instrument data memory. Returns 0 if it is successful or 1 if the test fails.

#### **\*CLS**

Clears the Status Byte summary register and event registers. Does not clear the Enable registers.

#### **\*OPC**

Sets the operation complete bit (bit 0) in the Standard Event register after a command is completed successfully.

#### **\*OPC?**

Returns an ASCII "1" after the command is executed.

#### **\*WAI**

After the command is executed, it prevents the instrument from executing any further query or commands until the no-operation-pending flag is TRUE.

**\*ESR?**

Queries the power-on status clear setting. Returns 0 or 1.

**\*ESE <value>**

Standard Event enable register controls which bits will be logically ORed together to generate the Event Summary bit 5 (ESB) within the Status Byte.

**\*ESE?**

Queries the Standard Event enable register. Returns the decimal value of the binary-weighted sum of bits.

**\*STB?**

Read the Status Byte. Returns the decimal value of the binary-weighted sum of bits.

**\*SRE <value>**

Service Request enable register controls which bits from the Status Byte should be used to generate a service request when the bit value = 1.

**\*SRE?**

Queries the Service Request enable register. Returns the decimal value of binary-weighted sum of bits.

**\*PSC {1|0}**

Sets the power-on status clear bit. When set to 1 the Standard Event Enable register and Status Byte Enable registers will be cleared when power is turned ON. 0 setting indicates the Enable registers will be loaded with Enable register masks from non-volatile memory at power ON.

**\*PSC?**

Queries the power-on status clear setting. Returns 0 or 1.

## CHAPTER 9. Calibration Procedure

EEC offers a standard one-year manufacture's warranty. This warranty can be extended an additional four years provided that the instrument is returned each year to EEC for it's annual calibration. In order to be eligible for the extended warranty instruments must be returned to EEC for calibration service at least once every twelve months.

Follow calibration is an example for model EAC-303.

### 9.1 Enter Calibration Mode

To enter the calibration mode power on the unit while holding the 4 key on the numeric keypad. When in the calibration mode the display will look as follows:

CALIBRATION			
3Ø4W CAL Func.		Λ	
1Ø2W CAL Func.		V	
		Select	
		Exit	

Use the up or down arrow soft keys to navigate to the parameter that you would like to calibrate. The parameters available for calibration are Voltage 150.0V, Voltage 300.0 V, Current xx.xxA, Power xxxxW, and A-Peak xx.xA. The actual values for the Current, Power, and A-Peak will change according to the model number. For example if you are calibrating the EAC the readings will be Current 2.0A, Current 36.00A, Power 4000W, and A-Peak 52.0A. Use the Select soft key to select the parameter for calibration. If you press the Exit soft key from this screen you will be kicked out of the Calibration mode and returned to the set screen.

#### 9.1.1 Calibration of Voltage 150.0V

Use the up or down arrow soft keys to navigate to the Voltage 150.0V parameter and press the Select soft key.

CALIBRATION 3Ø4W: R Phase			
Connect the standard 150VAC voltmeter from output R to N.			
Press TEST to start calibration. Press Exit to cancel.		Exit	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for voltage. If you press the Exit soft

key at this screen you return to the calibration mode screen.

CALIBRATION 3Ø4W: R Phase	
Voltage 150.0V	A V Select <More>
Voltage 300.0V	
Current 0.900A	
Current 9.00A	
A-Peak 12.7A	

CALIBRATION 3Ø4W: R Phase	
Enter standard voltage reading.	Enter Esc
Voltage = <input type="text"/>	
Press Esc to cancel.	

Enter the voltage reading from the voltmeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter Voltage 300.0V. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.2 Calibration of Voltage 300.0V

Use the up or down arrow soft keys to navigate to the Voltage 300.0V parameter and press the Select soft key.

CALIBRATION 3Ø4W: R Phase	
Connect the standard 300VAC voltmeter from output R to N.	Exit
Press TEST to start calibration.	
Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for voltage. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 3Ø4W: R Phase	
Enter standard voltage reading.	Enter Esc
Voltage = <input type="text"/>	
Press Esc to cancel.	

Enter the voltage reading from the voltmeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter Current xx.xA. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.3 Calibration of High & Low Current Range

Use the up or down arrow soft keys to navigate to the Current x.xxxA, or Current xx.xxA parameter and press the Select soft key.

CALIBRATION 3Ø4W:R Phase	
Connect the 112Ω load in series with the 0.900AAC current meter from output R to N.	Exit
Press TEST to start calibration.	
Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 3Ø4W:R Phase	
Enter standard current reading.	Volt +
current = <input type="text"/>	Volt -
Press Esc to cancel.	Enter
	Esc





Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.4 Calibration of High & Low Power Range

Use the , soft keys to navigate to Power xx.xW, or Power xxxxW parameter and press the Select soft key.



CALIBRATION	
Connect the 12Ω load in series with the 1000W power meter from output L to N.	Exit
Press TEST to start calibration.	
Press Exit to cancel.	





Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for wattage. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION	
Enter standard power reading.	Volt+ 
Power = <input type="text" value="---. -W"/>	Volt- 
	Enter 
Press Esc to cancel.	Esc 





Enter the power reading from the wattmeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper wattage value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.5 Calibration of Peak Current

Use the ,  soft keys to navigate to the A-Peak xx.xA parameter and press the Select soft key.

CALIBRATION 3Ø4W: R Phase	
Connect the 12Ω load in series with the 12.7AAC Peak current meter from output R to N.	   
Press TEST to start calibration.	
Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 3Ø4W: R Phase	
Enter standard A-Peak reading.	Volt+ 
current = <input type="text"/>	Volt- 
	Enter 
Press Esc to cancel.	Esc 

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter Volt 150.0V. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper peak current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.6 Calibration of 1Ø2W CAL Func

Use the up or down arrow soft keys to navigate to the parameter that you would like to calibrate.

CALIBRATION		Λ	
3Ø4W CAL Func.		V	
1Ø2W CAL Func.		Select	
		Exit	

Use the Select soft key to select the parameter for calibration. If you press the Exit soft key from this screen you will be kicked out of the Calibration mode and returned to the set screen.

CALIBRATION 1Ø2W		Λ	
Current 1.800A	Curr_DC 14.00A	V	
Current 18.00A		Select	
A-Peak 25.4A		Exit	
Volt_DC 210.0V			
Volt_DC 420.0V			
Curr_DC 4.50A			

### 9.1.7 Calibration of current 1.800A

Use the up or down arrow soft keys to navigate to **current 1.800A** parameter and press the Select soft key.

CALIBRATION 1Ø2W			
Connect the 56Ω load in series with the 1.800AAC current meter from output R to N.			
Press TEST to start calibration. Press Exit to cancel.		Exit	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 1Ø2W		V o l t +	
Enter standard current reading.		V o l t -	
current = <input type="text"/>		Enter	
Press Esc to cancel.		Esc	

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.8 Calibration of current 18.00A

Use the up or down arrow soft keys to navigate to **current 18.00A** parameter

and press the Select soft key.

CALIBRATION 102W	
Connect the 6Ω load in series with the 18.00AAC current meter from output R to N.	
Press TEST to start calibration. Press Exit to cancel.	Exit

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 102W	
Enter standard current reading.	Volt +
current = <input type="text"/>	Volt -
Press Esc to cancel.	Enter
	Esc

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.9 Calibration of A-Peak 25.4A

Use the up or down arrow soft keys to navigate to **A-Peak 25.4A** parameter and press the Select soft key.

CALIBRATION 102W	
Connect the 6Ω load in series with the 25.4AAC Peak current meter from output R to N.	
Press TEST to start calibration. Press Exit to cancel.	Exit

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION 102W	
Enter standard A-Peak reading.	Volt +
current = <input type="text"/>	Volt -
Press Esc to cancel.	Enter
	Esc

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the

next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

#### 9.1.10 Calibration of Low volt (DC)

Use the up or down arrow soft keys to navigate to **Volt\_DC 210.0V** parameter and press the Select soft key.

CALIBRATION 102W	
Connect the standard 210VDC voltmeter from output R to N.	Exit
Press TEST to start calibration. Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION DC MODE	
Enter standard voltage reading.	Enter Esc
Voltage = <input type="text"/>	
Press Esc to cancel.	

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. If you press the Esc soft key you will be returned to the calibration mode screen.

#### 9.1.11 Calibration of High volt (DC)

Use the up or down arrow soft keys to navigate to **Volt\_DC 420.0V** parameter and press the Select soft key.

CALIBRATION 102W	
Connect the standard 420VDC voltmeter from output R to N.	Exit
Press TEST to start calibration. Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION DC MODE	
Enter standard voltage reading.	Enter Esc
Voltage = <input type="text"/>	
Press Esc to cancel.	

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.12 Calibration of Low current (DC)

Use the up or down arrow soft keys to navigate to **Curr\_DC 4.50A** parameter and press the Select soft key.

CALIBRATION 102W	
Connect the 23Ω load in series with the 4.50AAC current meter from output R to N.	Exit
Press TEST to start calibration.	
Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION DC MODE	
Enter standard current reading.	Volt+ Volt- Enter Esc
current = <input type="text"/>	
Press Esc to cancel.	

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

### 9.1.13 Calibration of High current (DC)

Use the up or down arrow soft keys to navigate to **Curr\_DC 14.00A** parameter and press the Select soft key.

CALIBRATION 102W	
Connect the 8Ω load in series with the 14.00AAC current meter from output R to N.	Exit
Press TEST to start calibration. Press Exit to cancel.	

Follow the prompt message provided on the display, and press the Test/Reset button to move into the calibration screen for current. If you press the Exit soft key at this screen you return to the calibration mode screen.

CALIBRATION DC MODE	
Enter standard current reading.	Volt +
current = <input type="text"/>	Volt -
Press Esc to cancel.	Enter
	Esc

Enter the current reading from the ammeter with the numeric keypad. When the value has been selected press the Enter soft key and you will be moved to the next calibration parameter. The soft keys Volt+ and Volt- are available, if needed, to adjust the voltage output of the instrument to set a proper current value if a non-recommended load is used. If you press the Esc soft key you will be returned to the calibration mode screen.

## 9.2 Reference for Calibration

3 phase Calibration Item		Unit	EAC-303	EAC-306	EAC-303S	EAC-306S
Low Voltage Range	Calibration points	V	150.0	150.0	150.0	150.0
High Voltage Range	Calibration points	V	300.0	300.0	300.0	300.0
Low Current Range	Calibration points	A	0.900	1.800	0.900	1.800
	Suggest resistance	Ω	112	56	112	56
High Current Range	Calibration points	A	9.00	18.00	9.00	18.00
	Suggest resistance	Ω	12	6	12	6
High Peak Current Range	Calibration points	A	12.7	25.4	12.7	25.4
	Suggest resistance	Ω	12	6	12	6

1 phase Calibration Item		Unit	EAC-303	EAC-306
Low Voltage Range	Calibration points	A	1.800	3.60
	Suggest resistance	Ω	56	28
High Voltage Range	Calibration points	A	18.00	36.00
	Suggest resistance	Ω	6	3

High Peak Current Range	Calibration points	A	25.4	50.9
	Suggest resistance	$\Omega$	6	3
DC Low Voltage Range	Calibration points	V	210	210
DC High Voltage Range	Calibration points	V	420	420
DC Low Current Range	Calibration points	A	4.50	9.00
	Suggest resistance	$\Omega$	23	12
DC High Current Range	Calibration points	A	14.00	28.00
	Suggest resistance	$\Omega$	8	4

## CHAPTER 10. Options

### 10.1 GPIB Interface

This option provides the GPIB interface card in place of the standard USB/RS-232 interface.

### 10.2 Smart Config

This feature allows the operator to change the output of AC power source's Polyphase (3Ø4W) mode to single phase (1Ø2W and 1Ø3W) or DC mode with a simple button push. Changing the internal cables or dip switches is not required.


From the main menu press **<more>**, then **SYSTEM**, select **Function** and press Edit. This will allow the user to select: 1Ø2W, 3Ø4W or 1Ø3W.

To switch to DC mode, from the main menu select **<more>**, then **SYSTEM**, select Mode and press Edit. This will allow the user to select AC or DC.

### 10.3 Ethernet Card

The Ethernet Card option provides RS-232 and Ethernet communication interfaces, as well as barcode scanning capability.

The Ethernet Card has three input/output ports, shown in the following figure:



The port labeled “Barcode” is a PS/2-type connector that is used for the connection of a barcode scanner. The Ethernet port is for use with a standard CAT-5 Ethernet cable and may be connected to any compatible PC. The 9-pin D type subminiature connector labeled “RS232” is for connection of the EEC EAC series to an RS-232 communication bus.

#### RS-232 Interface

The protocol for interfacing and communicating using the RS-232 interface can be found in section **8. Bus Remote Interface GPIB/RS-232** of this manual.

#### Ethernet Interface

The Ethernet interface provides all of the function control of the standard RS-232 interface.

Some commands are only exclusive to GPIB control.

### Default Settings

The default settings for the Ethernet interface are as follows:

IP Setup: AUTO

IP Address: 010.000.000.000

Gateway IP: 000.000.000.000

Subnet Mask: 255.000.000.000

The source port number for the Ethernet Card in TCP connections is 10001.

### 10.3.1 Ethernet Card Setup

In order to setup the Ethernet card, the operator will need information from the local network administrator. Please have your network administrator fill out the required information on the next page and keep it for your records:

Ethernet Card Address: \_\_\_\_\_:\_\_\_\_\_:\_\_\_\_\_:\_\_\_\_\_:\_\_\_\_\_:

Device Name: \_\_\_\_\_


Device IP Address: \_\_\_\_\_.

Gateway IP Address: \_\_\_\_\_.


Subnet Mask: \_\_\_\_\_.

### 10.3.2 Saving New Settings

Upon startup, the Ethernet Card will take a few seconds to initialize. The following message will be displayed:



Any time the user edits one of the Ethernet Card parameters and exits the Ethernet Card Settings menu, the following message will be displayed:




The Ethernet Card will attempt to re-establish a connection with the server anytime the user modifies a parameter and exits the Ethernet Card Parameters Menu or uses the command set

at the end of this option description. Thus, if the IP Setup is set to AUTO, the Ethernet Card will request a new IP Address every time a parameter is edited and, as a result, the “Requesting IP Address. . .” message will appear.

### 10.3.3 Power Up


The Ethernet Card will be installed with the default options listed above. After the EEC EAC series initially powers up, the following pop-up message will appear:




**Note:** The “Requesting IP Address...” pop-up message only appears at power up when the Ethernet Card has its IP Setup configured to AUTO.

There are two options to choose from this screen. Press the Exit soft key to escape from this screen and stop the EEC EAC series from requesting an IP address or allow the EEC EAC series to request an IP address automatically from the network to which it is connected.

The Ethernet Card will wait for an IP Address for approximately 20 seconds. If the EEC EAC series successfully receives an IP Address from the server the following pop-up message will be displayed:



If the EEC EAC series fails to receive an IP Address after approximately 20 seconds, the following pop-up message will be displayed:



Press the Exit soft key to remove the pop-up message and return to the EEC EAC series’s Perform Tests screen.

### 10.3.4 Ethernet Card Menu

When the Ethernet Card option is installed, the ENET soft key will appear in the Perform Tests screen as shown below:

M 1-1 20.0s F: 50.0Hz CF: 0.00 Set A: 0.00A Ap: 0.0 P: 0Q VA: 0 Q: 0VARPF: 0.000	Result	
	System	
	ENET	
	<top>	

100.0 V 0.00 A

To access the Ethernet Card Menu, press the <more> soft key at the Perform Tests screen. Press the ENET soft key to display the Ethernet Card Parameters screen:

IP Setup	AUTO	
IP Address	192.152.100.130	^
Gateway IP	192.152.100.248	v
Subnet Ma	255.255.255.000	
Device Na	EXTECH	Edit
MAC Addre	00:20:4A:B0:6D:6D	
Barcode I	SERIAL#	
Autostart	OFF	Exit



### 10.3.5 IP Setup

Highlight the IP Setup parameter using the  ,  soft keys. When the IP Setup parameter is highlighted, press the Edit soft key.

IP Setup is used to determine how the EEC **EAC series** will request an IP address from the server to which it is connected. When AUTO is selected, the EEC **EAC series** will attempt to automatically request an IP Address from the server upon power up. To resolve the IP Address automatically, the EEC **EAC series** will use DHCP or BOOTP protocols. When MANUAL is selected, the EEC **EAC series** will request a specific IP Address from the server. The IP Address that will be requested must be entered in the subsequent IP Address parameter field.

Use the Change soft key to select how you would like the EEC **EAC series** to resolve an IP address. Press the Enter soft key to accept the new setting or the Exit soft key to cancel and return to the original setting.

### 10.3.6 IP Address


Highlight the IP Address parameter using the  ,  soft keys. When the IP Address parameter is highlighted, press the Edit soft key.

A specific IP Address must be entered into this field if the IP Setup parameter is configured to MANUAL. Enter the IP Address that you wish using the numeric keypad. The IP Address must be entered in the following format:

XXX.XXX.XXX.XXX. A valid IP Address must be entered. Users may not use the following IP Addresses:



255.255.255.255  
000.000.000.000

Enter the preceding IP Addresses will cause the following error message to be displayed:



Press the Exit soft key to save the new settings. If the IP Setup parameter is set to AUTO, you do not need to enter an IP Address manually.



### 10.3.7 Gateway IP

Highlight the Gateway IP parameter using the  ,  soft keys. When the Gateway IP parameter is highlighted, press the Edit soft key.


A specific Gateway IP must be entered into this field if the IP Setup parameter is configured to MANUAL. Enter the Gateway IP using the numeric keypad. The Gateway IP must be entered in the following format: XXX.XXX.XXX.XXX.

Press the Enter soft key to save the new settings. If the IP Setup parameter is set to AUTO, you do not need to enter a Gateway IP manually.

### 10.3.8 Subnet Mask

Highlight the Subnet Mask parameter using the  ,  soft keys. When the Subnet Mask parameter is highlighted, press the Edit soft key.



A specific Subnet Mask must be entered into this field if the IP Setup parameter is configured to MANUAL. Enter the Subnet Mask using the numeric keypad. The Subnet Mask must be entered in the following format: XXX.XXX.XXX.XXX. If an invalid Subnet Mask is entered the following error message will be displayed:







Press the Enter soft key to save the new settings. If the IP Setup parameter is set to AUTO,

you do not need to enter a Subnet Mask manually.





### 10.3.9 Device Name

Highlight the Device Name parameter using the  ,  soft keys. When the Device Name parameter is highlighted, press the Edit soft key.

The Device Name screen will appear as follows:

ABCDEF GHI JKLMNOPQR STUVWXYZ * _ ~ space	Device Name = EXTECH	>  v Select  <more>	   
--	-------------------------	------------------------------------	--

From this screen you may enter a Device Name for the EEC EAC series. The Device Name is used to identify the EEC EAC series on your server and may be used in place of a dedicated IP Address. Use the arrow keys to highlight a letter and press the Select soft key to select the highlighted letter. The Device Name may be a maximum of eight characters and MUST start with a letter. If the Device Name does not start with a letter the following error message will be displayed:

ABCDEF G JKLMNOP STUVWXY * _ ~ spa	DEVICE NAME ERROR! The device name must start with a letter.  PRESS EXIT TO CONTINUE	Exit	   
---	--	------	--



Enter to

When the Device Name has been entered, press the Enter soft key to save the new settings. The Device Name parameter is only active when the IP Setup is set to AUTO.

### 10.3.10 MAC Address

View the MAC address of the Ethernet Card here. This parameter is not adjustable.

### 10.3.11 Barcode Input

Highlight the Barcode INPUT parameter using the  ,  soft keys. When the Barcode INPUT parameter is highlighted, press the Edit soft key.

The Barcode INPUT parameter can be set to SERIAL#, PRODUCT#, SER/PROD, OFF or RUN FILE.

When the setting is SERIAL#, PRODUCT# or SER/PROD, the user can scan barcodes in the Perform Tests screen before the test is started. When a barcode is scanned, one of the following messages will appear on the display.

M 1-1 Set	20.0s F: 50.0Hz CF: 0.00	Serial Number: 0801A4D7	Exit
100			

M 1-1 Set	20.0s F: 50.0Hz CF: 0.00	Product Number: 38K502Z	Exit
100			

M 1-1 Set	20.0s F: 50.0Hz CF: 0.00	Serial Number: 0801A4D7 Product Number: 38K502Z	Exit
100			

After the barcodes are scanned, press Test to initiate the test sequence. Pressing Reset will abort the test sequence.

The Ethernet Card permits re-scanning of barcodes if the previously scanned barcode was incorrect. Re-scanning is only available in the SERIAL#, PRODUCT# and SER/PROD modes. If the user decides to re-scan barcodes when the Barcode INPUT setting is set to SER/PROD, the Ethernet Card will first replace the data in the Serial Number field, and if the user re-scans another barcode, the Ethernet Card will replace the data in the Product Number field.

The RUN FILE selection gives the user the ability to automatically load and execute a test file based on what barcode is scanned from the Perform Tests screen. In order for this feature to work, the user must name the desired test file with the exact alpha-numeric code that is on the product's barcode label. For example, if Product A has barcode "123456789", then the test file that the user would like to run when testing Product A should be named "123456789". When the product's barcode is scanned, the EEC EAC series will immediately execute the test associated with that barcode. The test file name is limited to 10 characters. However, if the user names a test file with the maximum 10 characters, this function will still initiate a test when a product's barcode begins with those first 10 characters even if the barcode has more than 10 characters.

# WARNING

Using the RUN FILE feature will enable the instrument's output once the barcode is scanned. Do not touch the DUT at any time when using this feature in order to avoid potential shock or serious injury.

For all types of tests two fields are added to the end of the standard response when the Barcode INPUT setting is set to SERIAL#, PRODUCT# or SER/PROD. The first field contains the Serial Number information and the second field contains the Product Number information. Both fields are included regardless of which of these three modes are selected. The Ethernet Card will substitute a "0" for the field if it is not applicable to the setting. For example, if a user had their Barcode INPUT setting set to SERIAL#, and scanned a Serial Number with the value "123456789", the TD? response for a test could be:


1,1,Pass,60.0,115.2,0.306,24.7,0.9,0.632,20.0,123456789,0

Note that there is a "0" in the Product Number field because the Barcode INPUT setting is SERIAL#.

When the Barcode INPUT setting is RUN FILE or OFF, these fields are not included in the TD? and RD x? responses.

Use the Change soft key to select the Barcode INPUT. Press the ENTER key to accept the new setting or the EXIT key to cancel and return to the original setting.

### 10.3.12 Autostart

Highlight the Autostart parameter using the  soft keys. When the Autostart parameter is highlighted, press the Edit soft key.

When Autostart is enabled, the test will execute as follows:

If the Barcode INPUT is set to PRODUCT#, scan the barcode once to input it into the EEC EAC series. The EEC EAC series will then search for a test file name that matches the product number barcode string. If the EEC EAC series finds a match, it will load the file into RAM.

#### **WARNING**

When the same product number barcode is scanned a second time, the test will be executed automatically. If EEC EAC series does not find a file name that matches the barcode string, the unit will beep – notifying the user that it did not find a matching file name. The test file name is limited to 10 characters. However, if the user names a test file with the maximum 10 characters, this function will still load a test file if the first 10 characters of the product number match the file name.

If the Barcode INPUT is set to SER/PROD, scan the serial number once to input it into the EEC EAC series. Next, scan the product number. From this point, EEC EAC series will operate the same as when the Barcode INPUT setting is set to PRODUCT#.

The Autostart feature will not work with the SERIAL# setting.

The Autostart feature will enable the instrument's output once the product number barcode is scanned a second time when in the PRODUCT# and SER/PROD modes. Do not touch the DUT at any time when using this feature in order to avoid potential shock or serious injury.

Use the Change soft key to select the Autostart setting. Press the Enter soft key to accept the new setting or the Exit soft key to cancel and return to the original setting.

### 10.3.13 Ethernet Card Settings Commands and Companion Queries

Command	Name	Value
SIM {1 0} SIM?	Set IP Mode	1=Manual, 0=Auto (DHCP/BOOTP)
SIA <value> SIA?	Set IP Address	Dotted decimal form. Ex. 192.168.1.50
SGA <value> SGA?	Set Gateway IP Address	Dotted decimal form
SSM <value> SSM?	Set Subnet Mask	Dotted decimal form
SDN <value> SDN?	Set Device Name	8 character max, must start with a letter
MAC?	MAC Address Query	Example response: 00:20:4A:8B:B4:30
SBI {4 3 2 1 0} SBI?	Set Barcode Input	0=Off, 1=Serial# and Product#, 2=Serial# Only, 3=Product#Only, 4=Run File
SAS {1 0} SAS?	Set Autostart	1=On, 0=Off

### Communication Considerations

- All of the above commands (excluding the query commands) will respond with the 06 hex (6 decimal) Acknowledge (ACK) ASCII control code if the transfer was recognized by the instrument.
- If there was an error with the command string, the instrument will respond with 15 hex (21 decimal), the Not Acknowledge (NAK) ASCII control code.
- However, the presence of this response does not mean that the instrument (in the case of these commands only) completed the command. These commands require a restarting of the hardware that controls the Ethernet Protocols. Because of this, the user

must wait before the Ethernet Card will respond to another command. See the table below for the approximate wait times necessary after one of the commands in the table is sent. In addition, the current socket connection between the user's terminal and the Ethernet Card is no longer valid, and the user will need to close their current connection and establish a new one.

### 10.3 Ethernet Card Settings Command Wait Times

IP Mode	Command	Wait Time After Command is Sent*
Manual	SIA, SGA, SSM	8 seconds
	SIM 0	14 seconds
Auto	SDN	14 seconds
	SIM 1	8 seconds

\*Wait times are approximate and can vary based on the user's network.